

# Acer Extensa 2700 Series

Service Guide

PRINTED IN TAIWAN

---

## Revision History

Please refer to the table below for the updates made on Extensa 2700 service guide.

Date	Chapter	Updates

---

## Copyright

Copyright © 2004 by Acer Incorporated. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Acer Incorporated.

## Disclaimer

The information in this guide is subject to change without notice.

Acer Incorporated makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any Acer Incorporated software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not Acer Incorporated, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software.

Intel is a registered trademark of Intel Corporation.

Pentium and Pentium II/III are trademarks of Intel Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

---

## Conventions

The following conventions are used in this manual:

<b>Screen messages</b>	Denotes actual messages that appear on screen.
<b>NOTE</b>	Gives bits and pieces of additional information related to the current topic.
<b>WARNING</b>	Alerts you to any damage that might result from doing or not doing specific actions.
<b>CAUTION</b>	Gives precautionary measures to avoid possible hardware or software problems.
<b>IMPORTANT</b>	Reminds you to do specific actions relevant to the accomplishment of procedures.

---

## Preface

Before using this information and the product it supports, please read the following general information.

1. This Service Guide provides you with all technical information relating to the BASIC CONFIGURATION decided for Acer "global" product offering. To better fit local market requirements and enhance product competitiveness, your regional office MAY have decided to extend the functionality of a machine (e.g. add-on card, modem, or extra memory capability). These LOCALIZED FEATURES will NOT be covered in this generic service guide. In such cases, please contact your regional offices or the responsible personnel/channel to provide you with further technical details.
2. Please note WHEN ORDERING FRU PARTS, that you should check the most up-to-date information available on your regional web or channel. If, for whatever reason, a part number change is made, it will not be noted in the printed Service Guide. For ACER AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code to those given in the FRU list of this printed Service Guide. You MUST use the list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

# Table of Contents

## Chapter 1 System Introduction 1

Features .....	1
System Block Diagram .....	3
Board Layout .....	4
Top View .....	4
Bottom View .....	5
Panel .....	6
Front View .....	6
Left view .....	7
Right View .....	8
Rear Panel .....	9
Bottom View .....	10
Indicators .....	11
Understanding the icons .....	12
Keyboard .....	13
Special keys .....	13
Hot Keys .....	16
Hardware Specifications and Configurations .....	19

## Chapter 2 System Utilities 32

BIOS Setup Utility .....	32
Navigating the BIOS Utility .....	33
Information .....	34
Main .....	35
Advanced .....	37
Security .....	39
Boot .....	43
Exit .....	44
BIOS Flash Utility .....	44

## Chapter 3 Machine Disassembly and Replacement 46

General Information .....	47
Before You Begin .....	47
Disassembly Procedure Flowchart .....	48
Removing the Battery .....	50
Removing the Memory Module .....	51
Removing the Wireless LAN Board and the Modem Board .....	52
Removing the Hard Disk Drive Module .....	53
Disassembling the Hard Disk Drive Module .....	53
Removing the LCD Module .....	54
Removing the Middle Cover .....	54
Removing the Launch Board .....	54
Removing the LCD Module .....	55
Disassembling the LCD Module .....	57
Removing the LCD Bezel .....	57
Removing the Inverter Board (15" LCD) .....	57
Removing the 15" TFT LCD .....	58
Removing the LCD Brackets .....	58
Removing the LCD Coaxial Cable .....	59
Removing the LCD Hinges .....	59
Disassembling the Main Unit .....	61
Removing the Keyboard .....	61

# Table of Contents

Removing the RTC Battery .....	61
Removing the Fan .....	61
Removing the Thermal Module .....	62
Removing the Processor .....	62
Installing the Processor .....	63
Removing the Upper Case Assembly .....	63
Removing the Touchpad Board .....	64
Removing the Touchpad Cable .....	64
Removing the VGA Thermal Plate .....	65
Removing the CPU Heatsink Plate .....	65
Removing the Second Fan Bracket .....	66
Removing the ODD Module(1) .....	66
Removing the ODD Module(2) .....	66
Removing the HDD Bracket .....	67
Removing the Main Board .....	67
Removing the DC Board .....	68
Removing the I/O Port Bracket .....	68
Removing the PCMCIA Slot .....	69
Removing the Speaker Set .....	70
System Upgrade Procedure .....	71
Base Unit to Wireless Unit .....	71
<b>Chapter 4 Troubleshooting</b> .....	<b>72</b>
System Check Procedures .....	73
External Diskette Drive Check .....	73
External CD-ROM Drive Check .....	73
Keyboard or Auxiliary Input Device Check .....	73
Memory check .....	74
Power System Check .....	74
Touchpad Check .....	76
Power-On Self-Test (POST) Error Message .....	77
Index of Error Messages .....	78
Index of Symptom-to-FRU Error Message .....	81
Intermittent Problems .....	84
Undetermined Problems .....	85
How to Build NAPP Master Hard Disc Drive .....	86
CD to Disk Recovery .....	86
Disk to Disk Recovery .....	89
<b>Chapter 5 Jumper and Connector Locations</b> .....	<b>94</b>
Top View .....	94
Bottom View .....	96
<b>Chapter 6 FRU (Field Replaceable Unit) List</b> .....	<b>98</b>
Extensa 2700 Exploded Diagram .....	99
<b>Appendix A Model Definition and Configuration</b> .....	<b>112</b>
Model Name Definition .....	112
<b>Appendix B Test Compatible Components</b> .....	<b>114</b>
Microsoft Windows XP Environment Test .....	115







# System Introduction

---

## Features

This computer was designed with the user in mind. Here are just a few of its many features:

### Performance

- ☐ Intel® Pentium® 4 Processor 2.80 ~ 3.06GHz  
Intel® Pentium® 4 Processor 2.80 ~ 3.20GHz  
Intel® Pentium® 4 Prescott Processor 3.00 ~ 3.80GHz
- ☐ Intel® Hyper-Threading™ Technology
- ☐ 256/512MB of DDR333 SDRAM, upgradeable to 2048 MB with dual soDIMM modules
- ☐ High-capacity, Enhanced-IDE hard disk

### Display

- ☐ The 14.1" or 15" XGA (1024x768 resolution), or 15.0" SXGA+ (1400x1050 resolution) TFT LCD panel providing a large viewing area for maximum efficiency and ease-of-use
- ☐ 3D graphics support
- ☐ Support simultaneous display between LCD and CRT
- ☐ S-video for output to a television or display device that supports S-video input
- ☐ "Automatic LCD dim" feature, automatically selecting the best setting for the display in order to conserve power
- ☐ Dual independent display support

### Multimedia

- ☐ High-speed built-in optical drive:  
DVD-RW, DVD/CD-RW Combo, or DVD-Dual
- ☐ MS DirectSound compatible
- ☐ Built-in dual speakers

### Connectivity

- ☐ Integrated 10/100 Mbps Fast Ethernet connection
- ☐ Built-in 56Kbps fax/data modem
- ☐ Four Universal Serial Bus (USB) 2.0 ports
- ☐ One IEEE 1394 port
- ☐ IEEE 802.11b or IEEE 802.11g Wireless LAN (manufacturing option)
- ☐ Bluetooth (manufacturing option)

### Expansion

- ☐ PC Card slots enabling a range of add-on options
- ☐ Upgradeable hard disk and memory modules

### Human-centric design


- ☐ Rugged, yet extremely portable, construction

- 
- ☐ Stylish appearance
  - ☐ Full-size keyboard with four programmable launch keys
  - ☐ Comfortable palm rest area with well-positioned touchpad

### ***I/O Ports***


- ☐ Two Type II or one Type III PC CardBus (PCMCIA) slot
- ☐ One IEEE 1394 port
- ☐ One FIR port
- ☐ One RJ-11 modem jack (V.92, 56K)
- ☐ One RJ-45 network jack
- ☐ One DC-in jack
- ☐ One parallel port (ECP/EPP)
- ☐ One S-video port
- ☐ One external monitor port
- ☐ One microphone-in jack (3.5mm mini jack)
- ☐ One headphone jack (3.5mm mini jack)
- ☐ Four USB ports

# System Block Diagram



# Board Layout


## Top View



1	CPU Socket	14	Line-in Port
2	Fan Connector	15	Line-out Port
3	SW1 (Please see Chapter 5 for detailed settings)	16	RJ45+RJ11
4	Touchpad Cable Connector	17	Four USB Ports
5	HDD Connector	18	VGA Port
6	Keyboard Connector	19	LCD Coaxial Cable Connector
7	Speaker Cable Connector	20	Mini PCI Connector
8	Optical Drive Connector	21	RTC Battery Connector
9	South Bridge	22	North Bridge
10	FDD Connector	23	Parallel Port
11	Launch Cable Connector	24	DC-in Port
12	PCMCIA Slot	25	LCD Lid Switch
13	LCD Inverter Cable Connector		

---

## Bottom View



- 1 FIR Port
- 2 Modem Cable Connector
- 3 Modem Card Connector
- 4 DIMM Socket 2
- 5 DIMM Socket 1

## Panel

Ports allow you to connect peripheral devices to your computer as you would with a desktop PC.


### Front View



#	Item	Description
1	Display screen	Also called LCD (Liquid Crystal Display), displays computer output.
2	Status indicators	LEDs (Light Emitting Diodes) that turn on and off to show the status of the computer and its functions and components.
3	Power button	Turns the computer on and off.
4	Launch Keys	Buttons for launching frequently used programs. <a href="#">See "Launch keys" on page 17 for more details.</a>
5	Palmrest	Comfortable support area for your hands when you use the computer.
6	Click buttons (left, center and right)	The left and right buttons function like the left and right mouse buttons, the center button serves as a scroll up/down button.
7	Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
8	Keyboard	Inputs data into your computer.
9	Ventilation Slot	Enables the computer to stay cool, even after the prolonged use.


## Left view



#	Icon	Item/ Port	Description
1		PC Card slots	Supports two Type II or one Type III CardBus PC Card(s).
2		Eject button	Eject PC cards from the card slots.
3		Optical drive	Internal optical drive; accepts CDs or DVDs depending on the optical drive type.
4		IEEE 1394 port	Connects to IEEE 1394 devices.
5		Infrared port	Interfaces with infrared devices (e.g., infrared printer, IR-aware computer).
6		LED indicator	Lights up when the optical drive is active.
7		Emergency eject slot	Ejects the optical drive tray when the computer is turned off. There is a mechanical eject button on the CD-ROM or DVD-ROM drive. Simply insert the tip of a pen or paperclip and push to eject the tray.
8		Eject button	Ejects the optical drive tray from the drive.
9		Speaker	Delivers stereo audio output.




**Right View**



#	Item/ Port	Description
1	Speaker	Delivers stereo audio output.
2	Ventilation slots	Enable the computer to stay cool, even after prolonged use.
3	Security keylock	Connects to a Kensington-compatible computer security lock.

**Rear Panel**

I



#	Icon	Port	Description
1		Power Jack	Connects to an AC adapter
2		Parallel port	Connects to a parallel device (e.g., parallel printer)
3		Ventilation slots	Enable the computer to stay cool, even after prolonged use.
4		S-video port	Connects to a television or display device with S-video input.
5		External display port	Connects to a display device (e.g., external monitor, LCD projector).
6		Four USB 2.0 ports	Connects to any Universal Serial Bus devices(e.g., USB mouse, USB camera).
7		Network jack	Connects to an Ethernet LAN network
8		Modem jack	Connects to the phone line
9		Speaker/line-out/ headphone jack	Connects to audio line-out devices (e.g., speakers and headphones).
10		Line-in/mic-in jack	Accepts audio line-in devices (e.g., audio CD player and stereo walkman).

---

## Bottom View



#	Item	Description
1	Battery bay	Houses the computer's battery pack.
2	Battery release latch	Unlatches the battery to remove the battery pack.
3	Memory compartment	Houses the computer's main memory.








---

## Indicators

The computer provides an array of seven indicators located below the display screen, showing the status of the computer and its components.



The Power and Sleep status icons are visible even when you close the display cover so you can see the status of the computer while the cover is closed.


#	Icon	Function	Description
		InviLink	Indicates status of wireless or Bluetooth (optional) communications. Orange--WLAN; Blue--Bluetooth
1		Power	Lights when the computer is on.
2		Sleep	Lights when the computer enters Standby mode and blinks when it enters into or resumes from hibernation mode.
3		Media Activity	Lights when the floppy drive, hard disk or optical drive is active.
4		Battery Charge	Lights when the battery is being charged.
5		Caps Lock	Lights when Caps Lock is activated.
6		Num Lock	Lights when Numeric Lock is activated.

---

## Understanding the icons

When the cover of your computer is closed, 2 easy-to-read icons are shown, indicating which state or feature is enabled or disabled.



#	Icon	Function	Description
1		Power	Lights up when the computer is on.
2	<b>Z<sup>Z</sup></b>	Sleep	Lights when the computer enters Standby mode and blinks when it enters into or resumes from hibernation mode.

# Keyboard








The keyboard has full-sized keys and an embedded keypad, separate cursor keys, two Windows keys and twelve function keys.

## Special keys

### Lock keys

The keyboard has three lock keys which you can toggle on and off.



Lock key	Description
Caps Lock 	When  is on, all alphabetic characters typed are in uppercase.
Num Lock (Fn-F11) 	When  is on, the embedded keypad is in numeric mode. The keys function as a calculator (complete with the arithmetic operators ), -, *, and /). Use this mode when you need to do a lot of numeric data entry. A better solution would be to connect an external keypad.
Scroll Lock (Fn-F12) 	When  is on, the screen moves one line up or down when you press the up or down arrow keys respectively.  does not work with some applications.

---

### ***Embedded numeric keypad***

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.












Desired access	Num lock on	Num lock off
Number keys on embedded keypad	Type numbers using embedded keypad in a normal manner.	
Cursor-control keys on embedded keypad	Hold Shift while using cursor-control keys.	Hold Fn while using cursor-control keys.
Main keyboard keys	Hold Fn while typing letters on embedded keypad.	Type the letters in a normal manner.

## Windows keys

The keyboard has two keys that perform Windows-specific functions.



Keys	Description
Windows logo key 	Start button. Combinations with this key perform shortcut functions. Below are a few examples:   + Tab (Activates next taskbar button)   + E (Explores My Computer)   + F (Finds Document)   + M (Minimizes All)   +  + M (Undoes Minimize All)   + R (Displays the Run... dialog box)
Application key 	Opens a context menu (same as a right-click).











## Hot Keys

The computer employs hot keys or key combinations to access most of the computer's controls like screen contrast and brightness, volume output and the BIOS Utility.

To activate hot keys, press and hold the **Fn** key before pressing the other key in the hot key combination.




Hot Key	Icon	Function	Description
Fn- <b>F1</b>	?	Hotkey help	Displays a list of the hotkeys and their functions.
Fn- <b>F2</b>		Setup	Accesses the notebook configuration utility.
Fn- <b>F3</b>		Power Management Scheme Toggle	Switches the power management scheme used by the computer (function available if supported by operating system).
Fn- <b>F4</b>	<b>Z<sup>z</sup></b>	Sleep	Puts the computer in Sleep mode.
Fn- <b>F5</b>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both the display screen and external monitor.
Fn- <b>F6</b>		Screen blank	Turns the display screen backlight off to save power. Press any key to return.
Fn- <b>F7</b>		Touchpad Toggle	Turns the internal touchpad on and off.
Fn- <b>F8</b>		Speaker on/off	Turns the speakers on and off; mutes the sound.
Fn- <b>F9</b>		Volume up	Increases the sound volume.
Fn- <b>F10</b>		Volume down	Decreases the sound volume.
Fn- <b>F11</b>		Brightness up	Increases the screen brightness.

Hot Key	Icon	Function	Description
Fn- 		Brightness down	Decreases the screen brightness.
Fn- 	Pg Up Home	Home	Functions as the  key.
Fn- 	Pg Dn End	End	Functions as the  key.
 Gr-Euro		Euro	Types the Euro symbol.

The Euro symbol

If your keyboard layout is set to United States-International or United Kingdom or if you have a keyboard with a European layout, you can type the Euro symbol on your keyboard.




**NOTE:** for US keyboard users: The keyboard layout is set when you first set up Windows. For the Euro symbol to work, the keyboard layout has to be set to United States-international.

To verify the keyboard type:

1. Click on **Start, Control Panel**.
2. Double-click on **Regional and Language Options**.
3. Click on the **Language** tab and click on **Details**.
4. Verify that the keyboard layout used for "En English (United States)" is set to United States-International. If not, select and click on **ADD**; then select **United States-International** and click on **OK**.
5. Click on **OK**.





To type the Euro symbol:

1. Locate the Euro symbol on your keyboard.
2. Open a text editor or word processor.
3. Hold  Gr and press the Euro symbol.

## Launch Keys

Located at the top of the keyboard are six buttons. These buttons are called launch keys. They are designated as mail button, Web browser button, P1, P2, Bluetooth and Wireless buttons. The Wireless and Bluetooth buttons cannot be set by the user. To set the other four launch keys, run the Acer Launch Manager.



#	Icon	Function	Description
1		Mail	Launches email application
2		Web browser	Launches Internet browser application
3	P1	P1	User-programmable
4	P2	P2	User-programmable
5		Bluetooth	Enables your Bluetooth (manufacturing option).
6		InviLink	Enables your 802.11b or 802.11g Wireless LAN.

# Hardware Specifications and Configurations

## System Board Major Chips

Item	Controller
System core logic	Intel® Pentium® processor+ATI Radeon 9000IGP
Super I/O controller	NS PC87392
Audio controller	Cirrus CS4299-XQ
Video controller	ATI Radeon 9000IGP
Hard disk drive controller	Embedded in Intel ICH4
Keyboard controller	Mitsubish LPC keyboard controller M38857
CardBus Controller	TI 1520
RTC	Intel ICH4

## Processor

Item	Specification
CPU type	Intel® Pentium® processor
CPU package	To 2.0GHz uFCBGA
CPU core voltage	High speed: 1.525V or 1.55V Low speed: 1.2V
CPU I/O voltage	High speed: 1.525V or 1.55V Low speed: 1.2V

## BIOS

Item	Specification
BIOS vendor	Phoenix BIOS
BIOS Version	
BIOS ROM type	Flash ROM
BIOS ROM size	512KB
BIOS package	32 Pin PLCC
Supported protocols	ACPI 2.0 (if available, at least 1.0b), SMBIOS 2.3, PCI 2.2, Boot Block, PXE 2.0, Mobile PC2001, Hard Disk Password, INT 13h Extensions, PCI Bus Power Management interface Specification, El Torito-Bootable CD-ROM Format Specification V1.0, Simple Boot Flag 1.0( Please review)
BIOS password control	Set by switch, see SW1 settings

## Second Level Cache

Item	Specification
Cache controller	Built-in CPU
Cache size	512KB
1st level cache control	Always Enabled
2nd level cache control	Always Enabled
Cache scheme control	Fixed-in write back

## System Memory

Item	Specification
Memory controller	
Onboard memory size	0MB
DIMM socket number	2 Sockets
Supports memory size per socket	128MB
Supports maximum memory size	2048MB (Please confirm if 1024MB has passed the test or not)
Supports DIMM type	DDR-DRAM
Supports DIMM Speed	333 MHz
Supports DIMM voltage	2.5 V
Supports DIMM package	200-pin so-DIMM
Memory module combinations	You can install memory modules in any combinations as long as they match the above specifications.

## Memory Combinations

Slot 1	Slot 2	Total Memory
0MB	128MB	128 MB
128MB	0MB	128 MB
128MB	128MB	256 MB
256MB	0MB	256MB
0MB	256MB	256MB
256MB	128MB	384MB
128MB	256MB	384MB
256MB	256MB	512MB
0MB	512MB	512MB
512MB	128MB	640MB
256MB	512MB	768MB
128MB	512MB	640MB
512MB	256MB	768MB
256MB	128MB	384MB
512MB	512MB	1024MB
0MB	512MB	512MB
1024MB	0MB	1024MB
1024MB	128MB	1152MB
1024MB	256MB	1280MB
1024MB	512MB	1536MB
0MB	1024MB	1024MB
128MB	1024MB	1152MB
256MB	1024MB	1280MB
512MB	1024MB	1536MB

Above table lists some system memory configurations. You may combine DIMMs with various capacities to form other combinations. Please confirm if I can insert different size memory on slot 1 and slot 2. For example, slot 1 uses 128MB, slot 2 uses 256MB or 512MB.

### LAN Interface

Item	Specification
Chipset	RealTek 8101L
Supports LAN protocol	10/100Mbps
LAN connector type	RJ45
LAN connector location	Rear side

### Modem Interface

Item	Specification
Chipset	Internal Agere Scorpio chipset (Scorpio+CSP1037B)
Fax modem data baud rate (bps)	14.4K
Data modem data baud rate (bps)	56K
Supports modem protocol	V.90/V.92MDC
Modem connector type	RJ11
Modem connector location	Rear side

### Hard Disk Drive Interface

Item			
Vendor & Model Name	HGST Moraga IC25N030ATMR04 Fujitsu V-40 MHT2030AT Seagate N1 ST93015A	HGST Moraga IC25N040ATMR04- TOSHIBA Pluto 40G MK4025GAS Fujitsu V40+ MHT2040AT Seagate N1 ST94019A	HGST Moraga IC25N060ATMR04-0 HGST Fresno DK23FA-60 TOSHIBA Neptune MK6021GAS
Capacity (MB)	30000	40000	60000
Bytes per sector	512	512	512
Logical heads	16	16	16
Logical sectors	63	63	63
Drive Format			
Logical cylinders	16383	16383	16383
Physical read/write heads	2/Not show/2	2/Not show/2/2	3/
Disks	1/Not show/1	1/Not show/1/1	2
Spindle speed (RPM)	4200RPM	4200RPM	4200RPM
Performance Specifications			
Buffer size	2MB	2MB/8MB for Toshiba	2MB
Interface	ATA-5 for other vendors /ATA-6 for HGST and Toshiba	ATA-5 for other vendors /ATA-6 for HGST	ATA-5 for other vendors /ATA-6 for HGST
Data transfer rate (disk-buffer, Mbytes/s)	350	350	350
Data transfer, rate (host-buffer, Mbytes/s)	100 MB/Sec	100 MB/Sec	100MB/Sec
DC Power Requirements			
Voltage tolerance	5 +/- 5%	5 +/- 5%	

## CD-ROM Interface

Items	Specification
Vendor & Model Name	QSI SCR242 Mitsumi SR244W1
Performance Specification	
Burst Data Transfer rate	PIO mode 4: 16.7 MB/sec Max. (Mode 0~4) Multi-word DMA mode 2: 16.7 MB/sec Max. (Mode 0~2) Ultra DMA mode 2: 33.3MB/sec Max.
Access time (typ.)	QSI- Random: 90 ms Full Stroke: 180 ms Mitsumi- Random: 100 ms Full Stroke: 240 ms
Rotation speed	5100 rpm for QSI 5400 rpm for Mitsumi 24X CAV mode
Data Buffer Capacity	128 KB (built-in)
Interface	Compliant to ATA/ATAPI-6
Applicable disc format	QSI: CD-DA, CD-ROM Mode-1, CD-ROM/XA Mode-2, Form-1 and Mode-2 Form-2, CD-i Ready, Video-CD (MPEG-1), Karaoke CD, Photo-CD, Enhanced CD, CD Plus, CD Extra, i-trax CD, CD-Text, CD-R and CD-RW Mitsumi: CD-DA, CD-ROM (Mode 1 and Mode2) CD-ROM XA (Mode 2 Form 1 and Form2), CD-I (Mode2 Form 1 and Form 2), CD-I Bridge (Photo CD, CD EXTRA), Enhanced CD, CD-RW, CD-R, CD-TEXT
Loading mechanism	Drawer with soft eject and emergency eject hole
Power Requirement	
Input Voltage	+5V[DC] +/-5%

## DVD-ROM Interface

Item	Specification	
Vendor & model name	MKE SR-8177	
Performance Specification	With CD Diskette	With DVD Diskette
Transfer rate (KB/sec)	Average Sustained: CAV mode 775~1800 blocks/sec (10.3X to 24X) 1550~3600kBytes/sec (Mode 1) 1768~4106 kBytes/sec (Mode 2)	DVD-5: Normal Speed (1X) 11.08 Mbits/sec CAV mode 36.67~88.64 Mbits/sec DVD-9/DVD-R: Normal Speed (1X) 11.08 Mbits/sec CAV mode 36.67~88.64 Mbits/sec

## DVD-ROM Interface

Item	Specification	
Average Full Access time (typ.)	Random CAV mode 110 msec typical 150 msec average max Full Stroke CAV mode 200 msec typical 260 msec average max	DVD-5: Random 120 msec typical 160 msec average max Full Stroke 270 msec typical 350 msec average max DVD-9: Random 150 msec typical 200 msec average max Full Stroke 340 msec typical 450 msec average max DVD-RAM (2.6G) Random 200 msec typical 300 msec average max Full Stroke 300 msec typical 600 msec average max DVD-RAM (4.7G) Random 180 msec typical 300 msec average max Full Stroke 320 msec typical 700 msec average max
Data Buffer Capacity	512 kBytes	
Interface	IDE	
Applicable disc format	DVD: DVD-5, DVD-9, DVD-10, DVD-R (3.95G), DVD-RAM (2.6G), DVD-RAM (4.7G) CD: CD-Audio, CD-ROM (mode 1 and mode 2), CD-ROM XA (mode 2, form 1 and form 2), CD-I (mode 2, form 1 and form 2), CD-I Ready, CD-I Bridge, CD-WO, CD-RW, Photo CD, Video CD, Enhanced Music CD, CD-TEXT	
Loading mechanism	Soft eject (with emergency eject hole)	
Power Requirement		
Input Voltage	+5V[DC] +/-5%	

## Combo Drive Interface

Item	Specification
Vendor & model name	KME UJDA750
Performance Specification	



## Combo Drive Interface

Item	Specification
Transfer rate (KB/sec)	Read Sustained: DVD-ROM MAX 8X CAV (MAX 10800 KB/sec) CD-ROM MAX 24X CAV (MAX 3600 KB/sec) Write: CD-R 4X, 8X (CLV), Max 16X, MAX 24X (ZCLV) CD-RW 4X (CLV) HS-RW 4X,8X, 10X (CLV) ATAPI Interface: PIO mode 16.6 MB/sec :PIO Mode 4 DMA mode 16.6 MB/sec:Multi word mode 2 Ultra DMA mode 33.3MB/sec: Ultra DMA mode 2
Buffer rate	2MB
Access time	DVD-ROM 180 ms typ. (1/3 stroke) CD-ROM 130 ms typ. (1/3 stroke)
Start up time	less than 15s
Stop time	less than 6s
Acoustic noise	less than 50 dBA
Interface	Enhanced IDE (ATAPI) compatible
Master/Slave	Set by Cable Select (By host)
PC compatible	PC2001 compatible
Applicable disc format	CD: CD-DA, CD-ROM, CD-ROM XA, CD-R, CD-RW, PhotoCD (multiSession), Video CD, CD-Extra(CD+), CD-text DVD: DVD-ROM, DVD-R, DVD-RW (Ver.1.1), DVD-VIDEO, DVD-RAM (2.6GB, 4.7GB)
Slope	15 degree (Any direction)
Dimensions, Weight	128X129X12.7mm (WXDXH) (except protrusion) 200g+- 10g
Eject	Soft Eject (with emergency eject hole)

## DVD Dual Interface

Item	Specification
Vendor & model name	Liteon DVD-Dual SDW-431S
Disc type for read/write application	
Applicable Formats	CD-DA, CD-TEXT, CD ROM Mode-1, CD-ROM/XA Mode-2 Form-1 and Form-2, CD-I Ready, Video-CD (MPEG-1), Karaoke-CD, Photo-CD, Enhance CD, CD extra, I-Trax CD and UDF DVD-ROM, DVD-Video, DVD-Audio, DVD-R single/multi border(s) DVD+R single/multi session(s) DVD-RW DVD+RW
Applicable Media Type	CD-ROM, CD-R and CD-RW DVD-ROM (4.7G/8.54G) single layer on single/double side (read only), DVD-ROM dual layer (PTP/OTP) on single/double side (read only) DVD-R (3.9G, 4.7G for General and Authoring), DVD-RW, DVD+RW (4.7G) DVD+R

## DVD Dual Interface

Item	Specification
Disc Diameter	12cm and 8cm
Capacity	2048 bytes/sector (DVD) 2048 bytes/block (CD Mode-1 and Mode-2 Form-1) 2336 bytes/block (Mode-2) 2328 bytes/block (Mode-2 Form-2)
Operation environment for "write/rewrite" application	
Host Machine	IBM compatible PC (Pentium 166 MHz or above)
OS	MS-Windows 90/ME/2000/XP/NT 4.0
Memory	Min. 128MB required
Hard Disk	Empty Storage Capacity:100 MB or more Average access time: 20ms or less
Disc Diameter	12cm and 8cm
Recommended Media	<p><b>CD-R:</b> AMT, CMC, Csita, Delphi, EverMedia, Imation, LeadData(Silver-Sil), Maxell, MCC (Bagdad), Mirage, Mitsui, MoserBaer(India), MPO, NanYa, Plasmon, Prodisc, RAMedia, Ricoh, Ritek(JS, S, Richodye), SAST (ultra green), SKC(Korea), TDK, TY (DX dye)</p> <p><b>Low Speed CD-RW:</b> CMC, Daxon, Fornet, Gigastorage, Imation, Infodisc, LeadData, MCC, Nanya, Princo, Prodisc, Ricoh, Ritek</p> <p><b>High Speed CD-RW:</b> AMT, CMC, Infodisc, Nanya, Postech, Prodisc, Ritek, Ricoh, MCC, SKC(Korea)</p> <p><b>Ultra Speed CD-RW:</b> Daxon, Imation, Infodisc, MCC, Prodisc, Ritek</p> <p><b>DVD+R:</b> BEALL, CMC, Daxon, Fuji, HP, Maxell, MCC, Memorex, OPTODISC, PRODISC, Ricoh, RICOH, Ritek, SONY, TDK, TYUDE</p> <p><b>DVD+RW:</b> CMMC, Daxon, Imation, MCC, Philips, Ricoh, Ritek, Sony</p> <p><b>DVD-R:</b> BeAll, CMMC, DAXON, DVSN Fornex, GSC, Imation, LeadData, Maxell, Mitsubishi, Nanya, Pioneer, Princo, Prodisc, Ritec, Ritek, SKC, Sony, That's</p> <p><b>DVD-RW:</b> CMC, Mitsubishi, Princo Ritek</p>
Mechanism	
Pick-up	<p>NA: CD: 0.51 DVD: 0.65</p> <p>Focusing: Astigmatism</p> <p>Tracking: CD: DPP DVD-ROM: DPD DVD+R/RW: DPP</p> <p>Wave length: CD: 785+/- 5 nm DVD: 650+/- 15 nm</p> <p>Output power: Read CD: 1.5 mw max@objective lens DVD: 1.0 mw max Write CD: 65 mw max2@objective lens DVD: 20 mw max</p>
Traverse mechanism	DC Stepping motor driven
Spindle motor	DC burshless motor

## DVD Dual Interface

Item	Specification
Loading mechanism	Manual load/DC brushless motor system

## Audio Interface

Item	Specification
Audio Controller	Cirrus Logic CS4299-XQ (RTL ALC655 which one is correct?)
Audio onboard or optional	Built-in
Mono or Stereo	Stereo
Resolution	20 bit stereo Digital to Analog converter 18 bit stereo Analog to Digital converter
Compatibility	Microsoft PC98/PC99, AC97 2.1
Mixed sound source	Line-in, CD, Video, AUX
Voice channel	8/16 bit, mono/stereo
Sampling rate	44.1 KHz
Internal microphone	Yes
Internal speaker / Quantity	Yes/2
Supports PnP DMA channel	DMA channel 0 DMA channel 1
Supports PnP IRQ	IRQ10, IRQ11

## Video Interface

Item	Specification
Vendor & Model Name	ATI Radeon 9000 IGP
Chip voltage	
Supports ZV (Zoomed Video) port	NO
Graph interface	4X AGP (Accelerated Graphic Port) Bus
Maximum resolution (LCD)	1024 x768 (32bit colors)
Maximum resolution (CRT)	1024x768 (32 bit colors) 1280x1024 (32 bit colors) 1600x1200 (32 bit colors)

## Video Memory

Item	Specification
Fixed or upgradeable	Fixed, share the system memory
Video memory size	64B(128MB optional)

## LCD Display Resolution

Resolution	8 bit (256colors)	16 bits (Hi color)	24 bits (True color)	32 bits (True color)
640x480	Yes	Yes	Yes	Yes
720x480	Yes	Yes	Yes	Yes
800x600	Yes	Yes	Yes	Yes
848x480	Yes	Yes	Yes	Yes
1024x768	Yes	Yes	Yes	Yes

### ***CRT Display Resolutions***

Resolution	8 bit (256colors)	16 bits (Hi color)	24 bits (True color)	32 bits (True color)
640x480	Yes	Yes	Yes	Yes
720x480	Yes	Yes	Yes	Yes
800x600	Yes	Yes	Yes	Yes
848x480	Yes	Yes	Yes	Yes
1024x768	Yes	Yes	Yes	Yes
1152x864	Yes	Yes	Yes	Yes
1280x1024	Yes	Yes	Yes	Yes
1400x1050	Yes	Yes	Yes	Yes
1600x1200	Yes	Yes	Yes	Yes

### ***Parallel Port***

Item	Specification
Parallel port controller	NS PC87392
Number of parallel port	1
Location	Rear side
Connector type	25-pin D-type
Parallel port function control	Enable/Disable by BIOS Setup
Supports ECP/EPP	Yes (set by BIOS setup)
Optional ECP DMA channel (in BIOS Setup)	DMA channel 1 and 3
Optional parallel port I/O address (in BIOS Setup)	378, 278
Optional parallel port IRQ (in BIOS Setup)	IRQ5, IRQ7

### ***USB Port***

Item	Specification
USB Compliance Level	2.0
OHCI	USB 2.0
Number of USB port	4
Location	Rear side

### ***PCMCIA Port***

Item	Specification
PCMCIA controller	TZ 1520
Supports card type	Type II, Type III
Number of slots	Two type II, one type III
Access location	Left side
Supports ZV (Zoomed Video) port	Yes
Supports 32 bit CardBus	Yes (IRQ17)

### Keyboard

Item	Specification
Keyboard controller	Mitsubishi LPC keyboard controller M38857
Keyboard vendor & model name	Darfon/Sunrex
Total number of keypads	84-/85- key
Windows keys	Yes
Internal & external keyboard work simultaneously	Yes

### Battery

Item	Specification
Vendor & model name	Sanyo/Simplo
Battery Type	Li-ION
Pack capacity	2000mAh per cell
Number of battery cell	8
Package configuration	4 serial 2 parallel
Output voltage	14.4Vdc (nominal)

### LCD

Item	Specification		
Vendor & model name	14.1" AU B141XN04 V2	15" Hitachi TX38D85VC1CAB	15" AU B150PG01 SXGA+
Physical Specifications			
Display resolution(pixel)	1024(H) x 768(V)	1400(H) x1050(V)	1400(H) x1050(V)
Active area(mm)	285.7(H) x 214.3(V)	304.1(H) x 228.1(V)	304.5 (H) x228.375(V)
Screen Size(inch)	14.1	15.0	15.0
Pixel pitch(mm)	0.279(H)x 0.279(V)	0.297(H)x 0.297(V)	0.2175x 0.2175
Color configuration (Pixel Arrangement)	R.G.B. Vertical stripe		
Overall dimension(mm)	298.5(W)x226.7(H)x5.2/5.5(D)	317.3(w)x242.1(H)x6.0(D)	
Weight(g)	445+/-20	580	550
Surface treatment	Hard coating (3H), anti-glare of the front polarizer	Not show	Not show
Power supply(input voltage)	3.6V(max)	3.3V(typ.) 3.6V(max)	3.3V
Response time:Rising time/Falling time	20(typ.)40(max)/ 30(typ.)50(max)	30(typ.)50(max) 30(typ.)50(max)	15(typ.) 35(typ.)
Contrast ratio	250	200	250
Support colors	262K	262k	262K
Typical White Luminance	150	180	150

### AC Adapter

Item	Specification
Vendor & model name	Liton
Input Requirements	
Maximum input current (A, @90Vac, full load)	1.5 A @ 110Vac 1.0 A @ 240Vac

## AC Adapter

Item	Specification
Nominal frequency (Hz)	50-60
Frequency variation range (Hz)	47-63
Input voltage range (Vrms)	90-270
Inrush current	The maximum inrush current will be less than 50A and 100A when the adapter is connected to 115Vac and 230Vac respectively.
Efficiency	It should provide an efficiency of 80% minimum, when measured at maximum load under 115Vac.
Output Ratings (CV mode)	
DC output voltage	19V
Noise + Ripple	300mVp-pmax (20 MHz bandwidth)
Load	0(min) 3.16A(max)
Output Ratings (CC mode)	
DC output voltage	19V +/-1.0V for CV mode
Constant current mode	3.6 +/- 0.3A
Dynamic Output Characteristics	
Turn-on delay time	3 sec (@ 115Vac)
Hold up time	5ms (@115Vac, Full load)
Over Voltage Protection (OVP)	24V
Short circuit protection	3.9A max can be protected and output can be shorted without damage
Electrostatic discharge (ESD)	15KV (at air discharge) 8KV (at contact discharge)
Dielectric Withstand Voltage	
Primary to secondary	3000Vac
Leakage current	0.25 mA max. (@ 254Vac, 60Hz)
Regulatory Requirements	<p>Safety Requirements:</p> <ol style="list-style-type: none"> <li>1.The subject product rated 100-120V 60Hz must be listed under UL 1950 and certified with SCA Standard C22.2 No.950.</li> <li>2.The subject product rated 200-240V 50Hz must comply with low voltage directive 73/23EEC.</li> </ol> <p>EMI Requirements:</p> <ol style="list-style-type: none"> <li>1.The subject product rated 100-120V 60Hz must meet the EMI requirements of FCC part 15, Subpart B for Class B Digital Device and get FCC Certification before marketing into USA and Canada.</li> <li>2.The subject product rated 200-240V 50Hz must meet the EMC Directive 89/336/EEC.</li> <li>3.The subject product rated 100-120V must meet the VCCI-2 EMI requirements.</li> </ol>

## Power Management

Power Saving Mode	Phenomenon
<p><b>Standby Mode</b></p> <p>Enter Standby Mode when</p> <ol style="list-style-type: none"> <li>1.Standby/Hibernation hot-key is pressed and system is not ready to enter Hibernation mode.</li> <li>2.System standby/ Hibernation timer expires and system is not ready to enter Hibernation mode.</li> </ol>	<input type="checkbox"/> The buzzer beeps <input type="checkbox"/> The Sleep indicator lights up

## Power Management

Power Saving Mode	Phenomenon
<b>Hibernation Mode</b> Enter Hibernation Mode (suspend to HDD) when 1.Hibernation hot-key is pressed and system is ready to enter Hibernation mode 2.System Hibernation timer expires and system is ready to enter Hibernation mode.	<input type="checkbox"/> All power shuts off
<b>Display Standby Mode</b> Keyboard, built-in touchpad, and an external PS/2 pointing device are idle for a specified period.	<input type="checkbox"/> The display shuts off
<b>Hard Disk Standby Mode</b> Hard disk is idle within a specified period of time.	<input type="checkbox"/> Hard disk drive is in standby mode. (spindle turned-off)

## Environmental Requirements

Item	Specification
<b>Temperature</b>	
Operating	+5~+35 °C
Non-operating	-20~+60 °C
<b>Humidity</b>	
Operating	10% to 95% RH, non-condensing without diskette 10% to 80% RH, non-condensing with diskette
Non-operating	20% to 80% RH, non-condensing (Unpacked)
Non-operating	20% to 90% RH, non-condensing (Storage package)
<b>Vibration</b>	
Operating	5~250Hz 0.5Grms, 15mins per axis
Non-operating (unpacked)	1.04 Grms, 2-200Hz 15 mins per axis
Non-operating (packed)	1.04 Grms, 2-200Hz 15 mins per axis

## Mechanical Specification

Item	Specification
Dimensions	322(W) x 294(D) x 39.4~39.9(H)mm
Weight	7.2 lbs for 14.1" TFT LCD model with battery/7.4 lbs for 15"LCD model with battery
I/O Ports	Two Type II or one Type III PC CardBus (PCMCIA) slot One IEEE 1394 port One FIR port One RJ-11 modem jack (V.92, 56K) One RJ-45 network jack One DC-in jack One parallel port (ECP/EPP) One S-video port One external monitor port One microphone-in jack (3.5mm mini jack) One headphone jack (3.5mm mini jack) Four USB ports
Drive Bays	One
Material	Plastic

---

***Mechanical Specification***

Item	Specification
Indicators	Power-on, Standby, Battery Status, Media Access, CapsLock and NumLock
Switch	Power



## System Utilities

### BIOS Setup Utility

The BIOS Setup Utility is a hardware configuration program built into your computer's BIOS (Basic Input/Output System).

Your computer is already properly configured and optimized, and you do not need to run this utility. However, if you encounter configuration problems, you may need to run Setup. Please also refer to Chapter 4 Troubleshooting when problem arises.

To activate the BIOS Utility, press **F2** during POST (when "Press <F2> to enter Setup" message is prompted on the bottom of screen).

Press **F2** to enter setup. The default parameter of F12 Boot Menu is set to "disabled". If you want to change boot device without entering BIOS Setup Utility, please set the parameter to "enabled".

Press <F12> during POST to enter multi-boot menu. In this menu, user can change boot device without entering BIOS SETUP Utility.

PhoenixBIOS Setup Utility					
Information	Main	Advanced	Security	Boot	Exit
CPU Type	Intel® Pentium® 4				
CPU Speed	2.8 GHz				
Floppy Drive:	Not installed				
HDD Model Name:	Toshiba MK3021GAS-(PM)				
HDD Serial Number:	Y3KJ2066TK				
ATAPI Model Name:	QSI CD-RW/DVD-ROM SBW242B-(SM)				
ATAPI Serial Number:	None				
System BIOS Version:	V0.18				
VGA BIOS Version:	008.0171.013.000				
KBC Version:	2.13.29				
Serial Number:	xxxxxxxxxxxxxxxxxxxx				
Asset Tag Number:	N/A				
Product Name:	TravelMate 2000	Displays product model names			
Manufacturer Name:	Acer				
UUID:	00000000-0000-0000-0000-00000000				
F1	Help	↑↓ Select Item	F5/F6 Change Values	F9	Setup defaults
Esc	Exit	↔ Select Menu	Enter Select ▸ Sub-Menu	F10	Save and Exit

---

## Navigating the BIOS Utility

There are six menu options: Info., Main, System Devices, Security, Boot, and Exit.

Follow these instructions:

- ❑ To choose a menu, use the cursor left/right keys (← →).
- ❑ To choose a parameter, use the cursor up/down keys (↑ ↓).
- ❑ To change the value of a parameter, press F5 or F6.
- ❑ A plus sign (+) indicates the item has sub-items. Press ENTER to expand this item.
- ❑ Press ESC while you are in any of the menu options to go to the Exit menu.
- ❑ In any menu, you can load default settings by pressing F9. You can also press F10 to save any changes made and exit the BIOS Setup Utility.

**NOTE:** You can change the value of a parameter if it is enclosed in square brackets. Navigation keys for a particular menu are shown on the bottom of the screen. Help for parameters are found in the Item Specific Help part of the screen. Read this carefully when making changes to parameter values.

This menu provides you the information of the system.

# Information

PhoenixBIOS Setup Utility					
Information	Main	Advanced	Security	Boot	Exit
CPU Type	Intel® Pentium® 4				
CPU Speed	2.8 GHz				
Floppy Drive:	Not installed				
HDD Model Name:	Toshiba MK3021GAS-(PM)				
HDD Serial Number:	Y3KJ2066TK				
ATAPI Model Name:	QSI CD-RW/DVD-ROM SBW242B-(SM)				
ATAPI Serial Number:	None				
System BIOS Version:	V0.18				
VGA BIOS Version:	008.0171.013.000				
KBC Version:	2.13.29				
Serial Number:	xxxxxxxxxxxxxxxxxxxx				
Asset Tag Number:	N/A				
Product Name:	TravelMate 2000	Displays product model names			
Manufacturer Name:	Acer				
UUID:	00000000-0000-0000-0000-00000000				
F1 Help	↑↓ Select Item	F5/F6 Change Values	F9	Setup defaults	
Esc Exit	←→ Select Menu	Enter Select	▸ Sub-Menu	F10	Save and Exit

**NOTE:** The system information is subject to different models.

Parameter	Description
Floppy Disk Drive	Shows floppy drive type informaiton. Note: Aspre 1620, Extensa 2700, TravelMate 2500 and Extnesa 2500 series products do not have floppy disk drive; Extensa 2000 and TravelMate 2000 series have floppy disk drive.
HDD Model Name	This field shows the model name of HDD installed on primary IDE master.
HDD Serial Number	This field displays the serial number of HDD installed on primary IDE master.
ATAPI Model Name	This field displays the mofel name of devices installed on secondary IDE master. The hard disk drive or optical drive model name is automatically detected by the system.
ATAPI Serial Number	This field shows the serial number of devices installed on secondary IDE master.
Serial Number	This field displays the serial number of this unit.
UUID Number	This will be visible only when an internal LAN device is presenting. UUID=32bytes

# Main

The Main screen displays a summary of your computer hardware information, and also includes basic setup parameters. It allows the user to specify standard IBM PC AT system parameters.

PhoenixBIOS Setup Utility					
Information	Main	Advanced	Security	Boot	Exit
Item specific Help					
System Time:	[22:58:45]				
System Date:	[03/18/2004]		<Tab>, <Shift-Tab>, or <Enter> selects field.		
System Memory:	640 KB	Show System Memory Size			
Extended Memory:	190 MB	Show Extened Memory Size			
VGA Memory:	64 MB	Video Memory Size			
Quiet Boot:	[Enabled]				
Power on display:	[Auto ]				
LCD Auto Dim:	[Enabled]				
PXE Boot From LAN:	[Enabled]				
F12 Boot Menu:	[Disabled]				
F1	Help	↑↓ Select Item	F5/F6 Change Values	F9	Setup defaults
Esc	Exit	↔ Select Menu	Enter Select ▸ Sub-Menu	F10	Save and Exit

**NOTE:** The screen above is for reference only. Actual values may differ.

The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Format/Option
System Time	Sets the system time. The hours are displayed with 24-hour format.	Format: HH:MM:SS (hour:minute:second) System Time
System Date	Sets the system date.	Format MM/DD/YYYY (month/day/year) System Date
System Memory	This field reports the memory size of the system. Memory size is fixed to 640MB	
Extended Memory	This field reports the memory size of the extended memory in the system. Extended Memory size=Total memory size-1MB	
VGA Memory	Shows the VGA memory size. VGA Memory size=64/128MB	
Fast Boot	Determines if Customer Logo will be displayed or not; shows Summary Screen is disabled or enabled.  Enabled: Customer Logo is displayed, and Summary Screen is disabled. Disabled: Customer Logo is not displayed, and Summary Screen is enabled.	Option: <b>Enabled</b> or Disabled
Power on display	Auto: During power process, the system will detect if any display device is connected on external video port. If any external display device is connected, the power on display will be in CRT (or projector) only mode. Otherwise it will be in LCD only mode.  Both: Simultaneously enable both the integrated LCD screen and the system's external video port (for an external CRT or projector).	Option: <b>Auto</b> or Both
LCD Auto Dim	Determines if the system will automatically dim the LCD brightness in order to save power when AC is not present.  The system will support an automatic dimming of the LCD backlight when the AC power is NOT available (running on battery power).	Option: <b>Enabled</b> or Disabled
PXE Boot from LAN	Enables, disables the system boot from LAN (remote server). PXE is the protocol.	Option: <b>Enabled</b> or Disabled
F12 Boot Menu	Enables, disables Boot Menu during POST.	Option: <b>Disabled</b> or Enabled

**NOTE:** The sub-items under each device will not be shown if the device control is set to disable or auto. This is because the user is not allowed to control the settings in these cases.

**NOTE:** If user disables "PXE Boot from LAN" option in BIOS Setup Utility, this item will be disappeared.

# Advanced

The Advanced menu screen contains parameters involving your hardware devices. It also provides advanced settings of the system.

PhoenixBIOS Setup Utility		
Information	Main	Advanced
		Security
		Boot
		Exit
		Item specific Help
Hyper-Threading Technology	[Enabled]	
Infrared Port (FIR):	[Disabled]	Configure Infrared Port using options:
Parallel Port:	[Enabled]	
Mode:	[ECP]	[Disabled]
Base I/O address:	[378]	No configuration
Interrupt::	[IRQ 7]	[Enabled]
DMA channel:	[DMA 1]	User configuration
Legacy USB Support:	[Disabled]	[Auto]
Event Logging		BIOS or OS chooses configuration
		(OS Controlled)
		Displayed when controlled by OS
F1 Help	↑↓ Select Item	F5/F6 Change Values
Esc Exit	←→ Select Menu	Enter Select ▶ Sub-Menu
		F9 Setup defaults
		F10 Save and Exit

The table below describes the parameters in the screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Options
Hyper-Threading Technology	The function is supported only when the CPU installed is 3.06G or above. The system will automatically hide this selection when detecting the CPU frequency is below 3.06G or the CPU does not support Hyper-Threading Technology.	<b>Enabled</b> /Disabled
Infrared Port	Enables, disables or auto detects the infrared port.	<b>Disabled</b> /Disabled/Auto
Parallel Port	Enables, disables or auto detects the parallel port.	<b>Enabled</b> /Disabled/Auto
Mode	Sets the operation mode of the parallel port.	<b>ECP</b> , EPP, Output only or Bi-directional
Base I/O address	Sets the I/O address of the parallel port.	<b>378</b> /278
Interrupt	Sets the interrupt request of the parallel port.	<b>IRQ7</b> /IRQ5
DMA channel	Sets a DMA channel for the printer to operate in ECP mode. This parameter is enabled only if Mode is set to ECP.	<b>DMA3</b> /DMA1

---

Parameter	Description	Options
Legacy USB Support	Enables, disables USB interface devices support under DOS mode.	Option: <b>Disabled</b> or Enabled

## Security

The Security screen contains parameters that help safeguard and protect your computer from unauthorized use.

PhoenixBIOS Setup Utility					
Information	Main	Advanced	Security	Boot	Exit
			Item specific Help		
User Password Is		Clear			
Supervisor Password Is		Clear		Supervisor Password controls access to the setup utility.	
Set User Password		[Enter]			
Set Supervisor Password		[Enter]			
Primary HardDisk Security:		[Disabled]			
Password on Boot:		[Disabled]			
F1	Help	↑↓	Select Item	F5/F6	Change Values
F9	Setup defaults				
Esc	Exit	←→	Select Menu	Enter	Select ▸ Sub-Menu
F10	Save and Exit				



The table below describes the parameters in this screen. Settings in **boldface** are the default and suggested parameter settings.

Parameter	Description	Option
User Password is	Shows the setting of the user password.	<b>Clear</b> or Set
Supervisor Password is	Shows the setting of the Supervisor password	<b>Clear</b> or Set
Set User Password	Press Enter to set the user password. When set, this password protects the BIOS Setup Utility from unauthorized access.	
Set Supervisor Password	Press Enter to set the supervisor password. When set, this password protects the BIOS Setup Utility from unauthorized access.	
Primary Harddisk Security	This feature is available to user when Supervisor password is set. Password can be written on HDD only when Supervisor password or user password is set and password on HDD is set to enabled. Supervisor Password is written to HDD only when Supervisor password is being set. User password is written to HDD when both passwords are set. When both Supervisor and user password are present, both passwords can unlock the HDD.	<b>Disabled</b> or Enabled
Password on Boot	Defines whether a password is required or not while the events defined in this group happened. The following sub-options are all requires the Supervisor password for changes and should be grayed out if the user password was used to enter setup.	<b>Disabled</b> or Enabled

**NOTE:** When you are prompted to enter a password, you have three tries before the system halts. Don't forget your password. If you forget your password, you may have to return your notebook computer to your dealer to reset it.

## Setting a Password

Follow these steps as you set the user or the supervisor password:

1. Use the **↑** and **↓** keys to highlight the Set Supervisor Password parameter and press the **ENTER** key. The Set Supervisor Password box appears:

Set Supervisor Password

Enter New Password      [                      ]

Confirm New Password    [                      ]

2. Type a password in the "Enter New Password" field. The password length can not exceeds 8 alphanumeric characters (A-Z, a-z, 0-9, not case sensitive). Retype the password in the "Confirm New Password" field.




**IMPORTANT:** Be very careful when typing your password because the characters do not appear on the screen.

3. Press **ENTER**.  
After setting the password, the computer sets the User Password parameter to "Set".
4. If desired, you can opt to enable the Password on boot parameter.
5. When you are done, press **F10** to save the changes and exit the BIOS Setup Utility.




---

## Removing a Password




Follow these steps:

1. Use the  and  keys to highlight the Set Supervisor Password parameter and press the  key. The Set Password box appears:




Set Supervisor Password		
Enter current password	[	]
Enter New Password	[	]
Confirm New Password	[	]

2. Type the current password in the Enter Current Password field and press .
3. Press  twice **without** typing anything in the Enter New Password and Confirm New Password fields. The computer then sets the Supervisor Password parameter to “Clear”.
4. When you have changed the settings, press  to save the changes and exit the BIOS Setup Utility.

## Changing a Password

1. Use the  and  keys to highlight the Set Supervisor Password parameter and press the  key. The Set Password box appears:

Set Supervisor Password		
Enter current password	[	]
Enter New Password	[	]
Confirm New Password	[	]

2. Type the current password in the Enter Current Password field and press .
3. Type a password in the Enter New Password field. Retype the password in the Confirm New Password field.
4. Press . After setting the password, the computer sets the User Password parameter to “Set”.
5. If desired, you can enable the Password on boot parameter.
6. When you are done, press  to save the changes and exit the BIOS Setup Utility.

If the verification is OK, the screen will display as following.

Setup Notice
Changes have been saved.
[ continue]

The password setting is complete after the user presses .

---

If the current password entered does not match the actual current password, the screen will show you the Setup Warning.


Setup Warning
Invalid password
Re-enter Password
[ continue]

If the new password and confirm new password strings do not match, the screen will display the following message.

Setup Warning
Password do not match
Re-enter Password


## Boot

This menu allows the user to decide the order of boot devices to load the operating system. Bootable devices includes the distette drive in module bay, the onboard hard disk drive and the CD-ROM in module bay.



# Exit

The Exit screen contains parameters that help safeguard and protect your computer from unauthorized use.



The table below describes the parameters in this screen.

Parameter	Description
Exit Saving Changes	Exit System Setup and save your changes to CMOS.
Exit Discarding Changes	Exit utility without saving setup data to CMOS.
Load Setup Default	Load default values for all SETUP item.
Discard Changes	Load previous values from CMOS for all SETUP items.
Save Changes	Save Setup Data to CMOS.

## BIOS Flash Utility

The BIOS flash memory update is required for the following conditions:

- ☐ New versions of system programs
- ☐ New features or options
- ☐ Restore a BIOS when it becomes corrupted.

Use the Phlash utility to update the system BIOS flash ROM.

**NOTE:** If you do not have a crisis recovery diskette at hand, then you should create a **Crisis Recovery**

---

**Diskette** before you use the Phlash utility.

**NOTE:** Do not install memory-related drivers (XMS, EMS, DPML) when you use the Phlash.

**NOTE:** Please use the AC adaptor power supply when you run the Phlash utility. If the battery pack does not contain enough power to finish BIOS flash, you may not boot the system because the BIOS is not completely loaded.

Follow the steps below to run the Phlash.

1. Prepare a bootable diskette.
2. Copy the Phlash utilities to the bootable diskette.
3. Then boot the system from the bootable diskette. The Phlash utility has auto-execution function.

## Machine Disassembly and Replacement

---

This chapter contains step-by-step procedures on how to disassemble the notebook computer for maintenance and troubleshooting.

To disassemble the computer, you need the following tools:

- ☐ Wrist grounding strap and conductive mat for preventing electrostatic discharge
- ☐ Flat-bladed screw driver
- ☐ Phillips screw driver
- ☐ Tweezers
- ☐ Plastic Flat-bladed screw driver
- ☐ Hexed Screw Driver

**NOTE:** The screws for the different components vary in size. During the disassembly process, group the screws with the corresponding components to avoid mismatch when putting back the components.

**NOTE:** This chapter has been revised from previous model (TravelMate 240/250). Please refer to the disassembling *procedures* instead of the *images*. Some of the images below contain the parts used in TravelMate 240/250, but not in Extensa 2700.

---

## ***General Information***

### ***Before You Begin***


Before proceeding with the disassembly procedure, make sure that you do the following:


1. Turn off the power to the system and all peripherals.
2. Unplug the AC adapter and all power and signal cables from the system.



## Disassembly Procedure Flowchart

The flowchart on the succeeding page gives you a graphic representation on the entire disassembly sequence and instructs you on the components that need to be removed during servicing. For example, if you want to remove the main board, you must first remove the keyboard, then disassemble the inside assembly frame in that order.





## Screw List

Item	Description
A	SCW HEX NYL I#R-40/O#4-40 L5.5(34.00015.081)
B	SCRW MACH PAN NYLOK M2.0*10 NI (86.1A522.100)
C	SCRW CPU SCREW FORCE 5KGS(86.T30V1.001)
D	SCREW M2*3 NYLON 1JMCPC-420325(86.9A352.3R0)
E	SCREW M2.5X6(86.9A353.6R0)
F	SRW M2.5*8L B/ZN NYLOK 700(86.9A353.8R0)
G	SCREW M3x4(86.9A524.4R0)
H	SCREW M2X2.0(86.9A552.2R0)
I	SCREW WAFER NYLOK NI 2ML3(86.9A552.3R0)
J	SCRW M2*4 WAFER NI(86.9A552.4R0)
K	SCRW M2.5*3 WAFER NI(86.9A553.3R0)
L	SCREW M2.5*4L NI(86.9A553.4R0)

---

## ***Removing the Battery***

1. To remove the battery, push the battery release latch.
2. Then slide the battery out from the machine.



---

## Removing the Memory Module

1. See “Removing the Battery” on page 50.
2. To remove the memory module from the machine, first remove the two screws holding the dimm cover.



3. Remove the dimm cover.



4. Pop up the memory.
5. Then remove the memory.



---

## Removing the Wireless LAN Board and the Modem Board

1. See “Removing the Battery” on page 50.
2. To remove the wireless LAN board, first remove the two screws holding the modem cover.



3. Remove the modem cover from the machine.
4. Disconnect the wireless antennae.



5. Pop out the wireless LAN board.
6. To remove the modem board, first remove the two screws fastening the modem board.




7. Detach the modem board and disconnect the modem cable carefully, then remove the modem board.




---

## ***Removing the Hard Disk Drive Module***

1. See “Removing the Battery” on page 50.
2. To remove the hard disk drive, pull the hard disk drive carefully.



3. Then take the hard disk drive out of the main unit.



## ***Disassembling the Hard Disk Drive Module***

1. See “Removing the Battery” on page 50.
2. See “Removing the Hard Disk Drive Module” on page 53.
3. Remove the two screws that fasten the HDD holder.



4. Detach the hard disk drive from the HDD holder.



---

## Removing the LCD Module

### Removing the Middle Cover

1. See “Removing the Battery” on page 50.
2. To remove the middle cover, first use a plastic flat screwdriver to remove the right hinge cap.
3. Remove the screw that secures the middle cover.




4. Remove the left hinge cap.
5. Then remove the screw holding the middle cover on the other side.



6. Detach the middle cover from the machine.




7. Disconnect the launch board cable then remove the middle cover off the main unit.



### Removing the Launch Board

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.

3. Remove the two screws and then detach the launch board from the middle cover.



## ***Removing the LCD Module***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Launch Board” on page 54.
4. Remove the screw that fastens the LCD coaxial cable and disconnect the cable. Then disconnect the LCD inverter cable.



5. Remove the four screws holding the LCD hinge; two on the right and two on the left. Remove the four screws holding the LCD hinge; two on the right and two on the left.




6. Remove the two screws on the bottom; one on the right and the other on the left.



7. Then you can remove the entire LCD module from the main unit.





---

## ***Disassembling the LCD Module***

### ***Removing the LCD Bezel***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Launch Board” on page 54.
4. See “Removing the LCD Module” on page 55.
5. Use plastic tweezers to remove the four screw pads, and then remove the four screws that fasten the LCD bezel.




6. Snap off the bezel carefully, and then remove the LCD bezel from the LCD module.



### ***Removing the Inverter Board (15" LCD)***


1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Launch Board” on page 54.
4. See “Removing the LCD Module” on page 55.
5. See “Removing the LCD Bezel” on page 57.
6. To remove the inverter board, first remove one screw from the inverter board.



7. Disconnect the LCD power cable then disconnect the inverter cable from the inverter board.



**NOTE:** Please arrange the LCD inverter cable well to the LCD panel as the picture below shows when you reassemble the LCD module.



### ***Removing the 15" TFT LCD***

1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.
3. See "Removing the Launch Board" on page 54.
4. See "Removing the LCD Module" on page 55.
5. See "Removing the LCD Bezel" on page 57.
6. See "Removing the Inverter Board (15" LCD)" on page 57.
7. To remove the LCD, first remove the four screws that secure the LCD hinges.




8. Then take the LCD out of the LCD panel.





### ***Removing the LCD Brackets***

1. See "Removing the Battery" on page 50.

2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Launch Board” on page 54.
4. See “Removing the LCD Module” on page 55.
5. See “Removing the LCD Bezel” on page 57.
6. See “Removing the Inverter Board (15" LCD)” on page 57.
7. See “Removing the 15" TFT LCD” on page 58.
8. Remove the four screws holding the right LCD bracket. Then remove the right bracket.



9. Remove the four screws holding the left LCD bracket. Then remove the left bracket.



### ***Removing the LCD Coaxial Cable***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Launch Board” on page 54.
4. See “Removing the LCD Module” on page 55.
5. See “Removing the LCD Bezel” on page 57.
6. See “Removing the Inverter Board (15" LCD)” on page 57.
7. See “Removing the 15" TFT LCD” on page 58.
8. Tear off the mylar fastening the LCD coaxial cable, then disconnect the coaxial cable.



### ***Removing the LCD Hinges***

1. See “Removing the Battery” on page 50.

- 
2. See “Removing the Middle Cover” on page 54.
  3. See “Removing the Launch Board” on page 54.
  4. See “Removing the LCD Module” on page 55.
  5. See “Removing the LCD Bezel” on page 57.
  6. See “Removing the Inverter Board (15" LCD)” on page 57.
  7. See “Removing the 15" TFT LCD” on page 58.
  8. Remove the screw holding the right hinge, then remove the right hinge.



9. Remove the screw holding the left hinge, then remove the left hinge.



---


## ***Disassembling the Main Unit***

### ***Removing the Keyboard***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. To remove the keyboard, carefully pull the keyboard out and upwards as the picture shows.



4. Use a plastic tweezers or a plastic flat screwdriver to disconnect the keyboard cable from the main board carefully, then remove the keyboard.




### ***Removing the RTC Battery***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. Disconnect the RTC battery cable then remove it.





### ***Removing the Fan***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. Disconnect the fan cable and remove the three screws fastening the fan. Then remove the fan.




## ***Removing the Thermal Module***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. See “Removing the Fan” on page 61.
5. Disconnect the fan cable then remove the four screws fastening the thermal module.





6. Then remove the thermal module.



## ***Removing the Processor***


1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. See “Removing the RTC Battery” on page 61.
5. See “Removing the Fan” on page 61.
6. See “Removing the Thermal Module” on page 62.
7. Lift up the CPU socket lever. Then remove the CPU. Remember to press down the lever as the video shows after you remove the CPU.







## ***Installing the Processor***

1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.
3. See "Removing the Keyboard" on page 61.
4. See "Removing the RTC Battery" on page 61.
5. See "Removing the Fan" on page 61.
6. See "Removing the Thermal Module" on page 62.
7. Lift up the CPU lever, then place the CPU back to the CPU socket. Please remember to press the CPU lever after you put the CPU back to the socket.




## ***Removing the Upper Case Assembly***

1. See "Removing the Keyboard" on page 61.
2. Disconnect the touchpad cable.



3. Remove the 5 screws that secure the upper case to the lower case. Then turn over the main unit and remove the 15 screws holding the lower case to the upper case.






4. Then take the upper case assembly off the main unit.



### ***Removing the Touchpad Board***

1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.
3. See "Removing the Keyboard" on page 61.
4. See "Removing the Upper Case Assembly" on page 63.
5. To detach the touch pad board, first disconnect the touch pad cable from the touch pad board with a plastic tweezers. Then release the touchpad cover lock on the back as the picture shows.




6. Remove the touchpad cover, then remove the touchpad button pad. Finally remove the touchpad board from the upper case.



### ***Removing the Touchpad Cable***


1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.

3. See “Removing the LCD Module” on page 55.
4. See “Removing the Keyboard” on page 61.
5. See “Removing the Upper Case Assembly” on page 63.
6. See “Removing the Touchpad Board” on page 64.
7. Remove the touchpad scroll key then remove the touchpad cable.




### ***Removing the VGA Thermal Plate***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. See “Removing the Fan” on page 61.
5. See “Removing the Thermal Module” on page 62.
6. Remove the seven screws holding the VGA thermal plate then remove it.



### ***Removing the CPU Heatsink Plate***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. See “Removing the Fan” on page 61.
5. See “Removing the Thermal Module” on page 62.
6. Remove the screw that fastens the CPU heatsink plate then remove it.



---

## ***Removing the Second Fan Bracket***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the LCD Module” on page 55.
4. See “Removing the RTC Battery” on page 61.
5. See “Removing the Fan” on page 61.
6. See “Removing the Thermal Module” on page 62.
7. Remove the three screws that fasten the second fan bracket then remove the bracket.



## ***Removing the ODD Module(1)***


1. See “Removing the Battery” on page 50.
2. Remove the screw that fastens the ODD bracket on the bottom. Push the ODD module at the point the red arrow indicates hard. Then remove the ODD module from the lower case.



**NOTE:** If you need to replace the ODD module only, you can remove the ODD module as the steps above.



## ***Removing the ODD Module(2)***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. See “Removing the Upper Case Assembly” on page 63.
5. See “Removing the Thermal Module” on page 62.
6. See “Removing the VGA Thermal Plate” on page 65.
7. Push the ODD module outwards then take the ODD out of the support bracket. Remove the screw that fastens the ODD support bracket then remove it.



## ***Removing the HDD Bracket***




1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.
3. See "Removing the Keyboard" on page 61.
4. See "Removing the Upper Case Assembly" on page 63.
5. Remove the four screws holding the HDD bracket, then remove the HDD bracket.



## ***Removing the Main Board***

1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.
3. See "Removing the Keyboard" on page 61.
4. See "Removing the Upper Case Assembly" on page 63.
5. See "Removing the Fan" on page 61.
6. See "Removing the Thermal Module" on page 62.
7. See "Removing the VGA Thermal Plate" on page 65.
8. See "Removing the CPU Heatsink Plate" on page 65.
9. See "Removing the Second Fan Bracket" on page 66.
10. See "Removing the ODD Module(2)" on page 66.
11. See "Removing the HDD Bracket" on page 67.
12. Disconnect the launch board cable. Tear off the tape that fastens the speaker set cable. Then disconnect the speaker set cable.






13. Remove the two screws holding the main board as the picture shows. Remove another two screws that fasten the main board. Then detach the main board from the lower case carefully.



### ***Removing the DC Board***

1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.
3. See "Removing the Keyboard" on page 61.
4. See "Removing the Upper Case Assembly" on page 63.
5. See "Removing the Fan" on page 61.
6. See "Removing the Thermal Module" on page 62.
7. See "Removing the VGA Thermal Plate" on page 65.
8. See "Removing the CPU Heatsink Plate" on page 65.
9. See "Removing the Second Fan Bracket" on page 66.
10. See "Removing the ODD Module(2)" on page 66.
11. See "Removing the HDD Bracket" on page 67.
12. See "Removing the Main Board" on page 67.
13. Remove the two screws that fasten the DC board. Then detach the DC board from the lower case.



### ***Removing the I/O Port Bracket***



1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.

3. See "Removing the Keyboard" on page 61.
4. See "Removing the Upper Case Assembly" on page 63.
5. See "Removing the Fan" on page 61.
6. See "Removing the Thermal Module" on page 62.
7. See "Removing the VGA Thermal Plate" on page 65.
8. See "Removing the CPU Heatsink Plate" on page 65.
9. See "Removing the Second Fan Bracket" on page 66.
10. See "Removing the ODD Module(2)" on page 66.
11. See "Removing the HDD Bracket" on page 67.
12. See "Removing the Main Board" on page 67.
13. Remove the four hex screws to detach the I/O port bracket from the main board.



### ***Removing the PCMCIA Slot***

1. See "Removing the Battery" on page 50.
2. See "Removing the Middle Cover" on page 54.
3. See "Removing the Keyboard" on page 61.
4. See "Removing the Upper Case Assembly" on page 63.
5. See "Removing the Fan" on page 61.
6. See "Removing the Thermal Module" on page 62.
7. See "Removing the VGA Thermal Plate" on page 65.
8. See "Removing the CPU Heatsink Plate" on page 65.
9. See "Removing the Second Fan Bracket" on page 66.
10. See "Removing the ODD Module(2)" on page 66.
11. See "Removing the HDD Bracket" on page 67.
12. See "Removing the Main Board" on page 67.
13. Remove the four screws that secure the PCMCIA slot, then remove the PCMCIA slot from the lower case.



---

## ***Removing the Speaker Set***

1. See “Removing the Battery” on page 50.
2. See “Removing the Middle Cover” on page 54.
3. See “Removing the Keyboard” on page 61.
4. See “Removing the Upper Case Assembly” on page 63.
5. See “Removing the Fan” on page 61.
6. See “Removing the Thermal Module” on page 62.
7. See “Removing the VGA Thermal Plate” on page 65.
8. See “Removing the CPU Heatsink Plate” on page 65.
9. See “Removing the Second Fan Bracket” on page 66.
10. See “Removing the ODD Module(2)” on page 66.
11. See “Removing the HDD Bracket” on page 67.
12. See “Removing the Main Board” on page 67.
13. See “Removing the DC Board” on page 68.
14. Tear off the tape fastening the speaker set cable. Then remove the four screws that secure the speaker set. Remove the speaker set from the lower case.

---

## System Upgrade Procedure

### Base Unit to Wireless Unit

1. Turn out the two screws fastening the modem cover then open the cover.
2. Connect the wireless antennae.
3. Insert the wireless LAN board to the wireless socket on the main board.
4. Close the modem cover and fasten the cover with the two screws.

**NOTE:** You must connect the wireless antennae before you insert the wireless LAN board to the socket. If you insert the wireless LAN card first, the pressure you press to fasten the wireless antennae may damage the main board.





## Troubleshooting

Use the following procedure as a guide for computer problems.

**NOTE:** The diagnostic tests are intended to test only Acer products. Non-Acer products, prototype cards, or modified options can give false errors and invalid system responses.

1. Obtain the failing symptoms in as much detail as possible.
2. Verify the symptoms by attempting to re-create the failure by running the diagnostic test or by repeating the same operation.
3. Use the following table with the verified symptom to determine which page to go to.

Symptoms (Verified)	Go To
Power failure. (The power indicator does not go on or stay on.)	"Power System Check" on page 74.
POST does not complete. No beep or error codes are indicated.	"Power-On Self-Test (POST) Error Message" on page 77 "Undetermined Problems" on page 85
POST detects an error and displayed messages on screen.	"Error Message List" on page 78
Other symptoms (i.e. LCD display problems or others).	"Power-On Self-Test (POST) Error Message" on page 77
Symptoms cannot be re-created (intermittent problems).	Use the customer-reported symptoms and go to "Power-On Self-Test (POST) Error Message" on page 77 "Intermittent Problems" on page 84 "Undetermined Problems" on page 85

---

## **System Check Procedures**

### **External Diskette Drive Check**

Do the following to isolate the problem to a controller, driver, or diskette. A write-enabled, diagnostic diskette is required.

**NOTE:** Make sure that the diskette does not have more than one label attached to it. Multiple labels can cause damage to the drive or cause the drive to fail.

Do the following to select the test device.

1. Boot from the diagnostics diskette and start the diagnostics program.
2. See if FDD Test is passed as the program runs to FDD Test.
3. Follow the instructions in the message window.

If an error occurs with the internal diskette drive, reconnect the diskette connector on the system board.

If the error still remains:

1. Reconnect the external diskette drive/DVD-ROM module.
2. Replace the external diskette drive/CD-ROM module.
3. Replace the main board.

### **External CD-ROM Drive Check**

Do the following to isolate the problem to a controller, drive, or CD-ROM. Make sure that the CD-ROM does not have any label attached to it. The label can cause damage to the drive or can cause the drive to fail.

Do the following to select the test device:

1. Boot from the diagnostics diskette and start the diagnostics program.
2. See if CD-ROM Test is passed when the program runs to CD-ROM Test.
3. Follow the instructions in the message window.

If an error occurs, reconnect the connector on the System board. If the error still remains:

1. Reconnect the external diskette drive/CD-ROM module.
2. Replace the external diskette drive/CD-ROM module.
3. Replace the main board.

### **Keyboard or Auxiliary Input Device Check**

Remove the external keyboard if the internal keyboard is to be tested.

If the internal keyboard does not work or an unexpected character appears, make sure that the flexible cable extending from the keyboard is correctly seated in the connector on the system board.

If the keyboard cable connection is correct, run the Keyboard Test.

If the tests detect a keyboard problem, do the following one at a time to correct the problem. Do not replace a non-defective FRU:

1. Reconnect the keyboard cables.
2. Replace the keyboard.
3. Replace the main board.

The following auxiliary input devices are supported by this computer:

- ☐ Numeric keypad
- ☐ External keyboard

If any of these devices do not work, reconnect the cable connector and repeat the failing operation.

---

## **Memory check**

Memory errors might stop system operations, show error messages on the screen, or hang the system.

1. Boot from the diagnostics diskette and start the doagmpstotics program (please refer to main board).
2. Go to the diagnostic memory in the test items.
3. Press F2 in the test items.
4. Follow the instructions in the message window.

**NOTE:** Make sure that the DIMM is fully installed into the connector. A loose connection can cause an error.

## **Power System Check**

To verify the symptom of the problem, power on the computer using each of the following power sources:

1. Remove the battery pack.
2. Connect the power adapter and check that power is supplied.
3. Disconnect the power adapter and install the charged battery pack; then check that power is supplied by the battery pack.


If you suspect a power problem, see the appropriate power supply check in the following list:

- ☐ "Check the Power Adapter" on page 75
- ☐ "Check the Battery Pack" on page 76

---

## Check the Power Adapter

Unplug the power adapter cable from the computer and measure the output voltage at the plug of the power adapter cable. See the following figure



1. If the voltage is not correct, replace the power adapter.
2. If the voltage is within the range, do the following:
  - ☐ Replace the System board.
  - ☐ If the problem is not corrected, see “Undetermined Problems” on page 85.
  - ☐ If the voltage is not correct, go to the next step.

**NOTE:** An audible noise from the power adapter does not always indicate a defect.

3. If the power-on indicator does not light up, check the power cord of the power adapter for correct continuity and installation.
4. If the operational charge does not work, see “Check the Battery Pack” on page 76.

---

## Check the Battery Pack


To check the battery pack, do the following:

From Software:

1. Check out the Power Management in control Panel
2. In Power Meter, confirm that if the parameters shown in the screen for Current Power Source and Total Battery Power Remaining are correct.
3. Repeat the steps 1 and 2, for both battery and adapter.
4. This helps you identify first the problem is on recharging or discharging.

From Hardware:

1. Power off the computer.
2. Remove the battery pack and measure the voltage between battery terminals 1(+) and 6(ground). See the following figure



3. If the voltage is still less than 7.5 Vdc after recharging, replace the battery.

To check the battery charge operation, use a discharged battery pack or a battery pack that has less than 50% of the total power remaining when installed in the computer.

If the battery status indicator does not light up, remove the battery pack and let it return to room temperature. Re-install the battery pack.

If the charge indicator still does not light up, replace the battery pack. If the charge indicator still does not light up, replace the DC/DC charger board.

## Touchpad Check

If the touchpad doesn't work, do the following actions one at a time to correct the problem. Do not replace a non-defective FRU:

1. Reconnect the touchpad cables.
2. Replace the touchpad.
3. Replace the system board.

After you use the touchpad, the pointer drifts on the screen for a short time. This self-acting pointer movement can occur when a slight, steady pressure is applied to the touchpad pointer. This symptom is not a hardware problem. No service actions are necessary if the pointer movement stops in a short period of time.

---

## ***Power-On Self-Test (POST) Error Message***

The POST error message index lists the error message and their possible causes. The most likely cause is listed first.

**NOTE:** Perform the FRU replacement or actions in the sequence shown in FRU/Action column, if the FRU replacement does not solve the problem, put the original part back in the computer. Do not replace a non-defective FRU.

This index can also help you determine the next possible FRU to be replaced when servicing a computer.

If the symptom is not listed, see “Undetermined Problems” on page 85.

The following lists the error messages that the BIOS displays on the screen and the error symptoms classified by function.

**NOTE:** Most of the error messages occur during POST. Some of them display information about a hardware device, e.g., the amount of memory installed. Others may indicate a problem with a device, such as the way it has been configured.

**NOTE:** If the system fails after you make changes in the BIOS Setup Utility menus, reset the computer, enter Setup and install Setup defaults or correct the error.

## Index of Error Messages

### Error Code List

Error Codes	Error Messages
006	Equipment Configuration Error Causes: 1. CPU BIOS Update Code Mismatch 2. IDE Primary Channel Master Drive Error (The causes will be shown before "Equipment Configuration Error")
010	Memory Error at xxxx:xxx:xxxh (R:xxxh, W:xxxh)
070	Real Time Clock Error
071	CMOS Battery Bad
072	CMOS Checksum Error
110	System disabled. Incorrect password is specified.
<No error code>	Battery critical LOW In this situation BIOS will issue 4 short beeps then shut down system, no message will show.
<No error code>	Thermal critical High In this situation BIOS will shut down system, not show message.

### Error Message List

Error Messages	FRU/Action in Sequence
Failure Fixed Disk	Reconnect hard disk drive connector. "Load Default Settings" in BIOS Setup Utility. Hard disk drive System board
Stuck Key	see "Keyboard or Auxiliary Input Device Check" on page 73.
Keyboard error	see "Keyboard or Auxiliary Input Device Check" on page 73.
Keyboard Controller Failed	see "Keyboard or Auxiliary Input Device Check" on page 73.
Keyboard locked - Unlock key switch	Unlock external keyboard
Monitor type does not match CMOS - Run Setup	Run "Load Default Settings" in BIOS Setup Utility.
Shadow RAM Failed at offset: nnnn	BIOS ROM System board
System RAM Failed at offset: nnnn	DIMM System board
Extended RAM Failed at offset: nnnn	DIMM System board
System battery is dead - Replace and run Setup	Replace RTC battery and Run BIOS Setup Utility to reconfigure system time, then reboot system.
System CMOS checksum bad - Default configuration used	RTC battery Run BIOS Setup Utility to reconfigure system time, then reboot system.
System timer error	RTC battery Run BIOS Setup Utility to reconfigure system time, then reboot system. System board

## Error Message List

Error Messages	FRU/Action in Sequence
Real time clock error	RTC battery Run BIOS Setup Utility to reconfigure system time, then reboot system. System board
Previous boot incomplete - Default configuration used	Run "Load Default Settings" in BIOS Setup Utility. RTC battery System board
Memory size found by POST differed from CMOS	Run "Load Default Settings" in BIOS Setup Utility. DIMM System board
Diskette drive A error	Check the drive is defined with the proper diskette type in BIOS Setup Utility See "External Diskette Drive Check" on page 73.
Incorrect Drive A type - run SETUP	Check the drive is defined with the proper diskette type in BIOS Setup Utility
System cache error - Cache disabled	System board
CPU ID:	System board
DMA Test Failed	DIMM System board
Software NMI Failed	DIMM System board
Fail-Safe Timer NMI Failed	DIMM System board
Device Address Conflict	Run "Load Default Settings" in BIOS Setup Utility. RTC battery System board
Allocation Error for device	Run "Load Default Settings" in BIOS Setup Utility. RTC battery System board
Failing Bits: nnnn	DIMM BIOS ROM System board
Fixed Disk n	None
Invalid System Configuration Data	BIOS ROM System board
I/O device IRQ conflict	Run "Load Default Settings" in BIOS Setup Utility. RTC battery System board
Operating system not found	Enter Setup and see if fixed disk and drive A: are properly identified. Diskette drive Hard disk drive System board



## Error Message List

No beep Error Messages	FRU/Action in Sequence
No beep, power-on indicator turns off and LCD is blank.	Power source (battery pack and power adapter). See "Power System Check" on page 74. Ensure every connector is connected tightly and correctly. Reconnect the DIMM. LED board. System board.
No beep, power-on indicator turns on and LCD is blank.	Power source (battery pack and power adapter). See "Power System Check" on page 74. Reconnect the LCD connector Hard disk drive LCD inverter ID LCD cable LCD Inverter LCD System board
No beep, power-on indicator turns on and LCD is blank. But you can see POST on an external CRT.	Reconnect the LCD connectors. LCD inverter ID LCD cable LCD inverter LCD System board
No beep, power-on indicator turns on and a blinking cursor shown on LCD during POST.	Ensure every connector is connected tightly and correctly. System board
No beep during POST but system runs correctly.	Speaker System board

## Index of Symptom-to-FRU Error Message

### LCD-Related Symptoms

Symptom / Error	Action in Sequence
LCD backlight doesn't work LCD is too dark LCD brightness cannot be adjusted LCD contrast cannot be adjusted	Enter BIOS Utility to execute "Load Setup Default Settings", then reboot system. Reconnect the LCD connectors. Keyboard (if contrast and brightness function key doesn't work). LCD inverter ID LCD cable LCD inverter LCD System board
Unreadable LCD screen Missing pels in characters Abnormal screen Wrong color displayed	Reconnect the LCD connector LCD inverter ID LCD cable LCD inverter LCD System board
LCD has extra horizontal or vertical lines displayed.	LCD inverter ID LCD inverter LCD cable LCD System board

### Indicator-Related Symptoms

Symptom / Error	Action in Sequence
Indicator incorrectly remains off or on, but system runs correctly	Reconnect the inverter board Inverter board System board

### Power-Related Symptoms

Symptom / Error	Action in Sequence
Power shuts down during operation	Power source (battery pack and power adapter). See "Power System Check" on page 74. Battery pack Power adapter Hard drive & battery connection board System board
The system doesn't power-on.	Power source (battery pack and power adapter). See "Power System Check" on page 74. Battery pack Power adapter Hard drive & battery connection board System board
The system doesn't power-off.	Power source (battery pack and power adapter). See "Power System Check" on page 74. Hold and press the power switch for more than 4 seconds. System board
Battery can't be charged	See "Check the Battery Pack" on page 76. Battery pack System board

### PCMCIA-Related Symptoms

Symptom / Error	Action in Sequence
System cannot detect the PC Card (PCMCIA)	PCMCIA slot assembly System board
PCMCIA slot pin is damaged.	PCMCIA slot assembly


### Memory-Related Symptoms

Symptom / Error	Action in Sequence
Memory count (size) appears different from actual size.	Enter BIOS Setup Utility to execute "Load Default Settings, then reboot system. DIMM System board

### Speaker-Related Symptoms

Symptom / Error	Action in Sequence
In Windows, multimedia programs, no sound comes from the computer.	Audio driver Speaker System board
Internal speakers make noise or emit no sound.	Speaker System board

### Power Management-Related Symptoms

Symptom / Error	Action in Sequence
The system will not enter hibernation	Keyboard (if control is from the keyboard) Hard disk drive System board
The system doesn't enter hibernation mode and four short beeps every minute.	See "Hibernation Mode" on page 30. Press Fn+  and see if the computer enters hibernation mode. Touchpad Keyboard Hard disk connection board Hard disk drive System board
The system doesn't enter standby mode after closing the LCD	See "Hibernation Mode" on page 30. LCD cover switch System board
The system doesn't resume from hibernation mode.	See "Hibernation Mode" on page 30. Hard disk connection board Hard disk drive System board
The system doesn't resume from standby mode after opening the LCD.	See "Hibernation Mode" on page 30. LCD cover switch System board
Battery fuel gauge in Windows doesn't go higher than 90%.	Remove battery pack and let it cool for 2 hours. Refresh battery (continue use battery until power off, then charge battery). Battery pack System board

### Power Management-Related Symptoms

Symptom / Error	Action in Sequence
System hangs intermittently.	Reconnect hard disk/CD-ROM drives. Hard disk connection board System board

### Peripheral-Related Symptoms

Symptom / Error	Action in Sequence
System configuration does not match the installed devices.	Enter BIOS Setup Utility to execute "Load Default Settings", then reboot system. Reconnect hard disk/CD-ROM/diskette drives.
External display does not work correctly.	Press Fn+F5, LCD/CRT/Both display switching System board
USB does not work correctly	System board
Print problems.	Ensure the "Parallel Port" in the "Onboard Devices Configuration" of BIOS Setup Utility is set to Enabled. Onboard Devices Configuration Run printer self-test. Printer driver Printer cable Printer System Board
Serial or parallel port device problems.	Ensure the "Serial Port" in the Devices Configuration" of BIOS Setup Utility is set to Enabled. Device driver Device cable Device System board

### Keyboard/Touchpad-Related Symptoms

Symptom / Error	Action in Sequence
Keyboard (one or more keys) does not work.	Reconnect the keyboard cable. Keyboard System board
Touchpad does not work.	Reconnect touchpad cable. Touchpad board System board

### Modem-Related Symptoms

Symptom / Error	Action in Sequence
Internal modem does not work correctly.	Modem phone port modem combo board System board

**NOTE:** If you cannot find a symptom or an error in this list and the problem remains, see "Undetermined Problems" on page 85.

---

## ***Intermittent Problems***

Intermittent system hang problems can be caused by a variety of reasons that have nothing to do with a hardware defect, such as: cosmic radiation, electrostatic discharge, or software errors. FRU replacement should be considered only when a recurring problem exists.

When analyzing an intermittent problem, do the following:

1. Run the advanced diagnostic test for the system board in loop mode at least 10 times.
2. If no error is detected, do not replace any FRU.
3. If any error is detected, replace the FRU. Rerun the test to verify that there are no more errors.

---

## Undetermined Problems

The diagnostic problems does not identify which adapter or device failed, which installed devices are incorrect, whether a short circuit is suspected, or whether the system is inoperative.

Follow these procedures to isolate the failing FRU (do not isolate non-defective FRU).

**NOTE:** Verify that all attached devices are supported by the computer.

**NOTE:** Verify that the power supply being used at the time of the failure is operating correctly. (See “Power System Check” on page 74):

1. Power-off the computer.
2. Visually check them for damage. If any problems are found, replace the FRU.
3. Remove or disconnect all of the following devices:
  - ☐ Non-Acer devices
  - ☐ Printer, mouse, and other external devices
  - ☐ Battery pack
  - ☐ Hard disk drive
  - ☐ DIMM
  - ☐ CD-ROM/Diskette drive Module
  - ☐ PC Cards
4. Power-on the computer.
5. Determine if the problem has changed.
6. If the problem does not recur, reconnect the removed devices one at a time until you find the failing FRU.
7. If the problem remains, replace the following FRU one at a time. Do not replace a non-defective FRU:
  - ☐ System board
  - ☐ LCD assembly

---


## How to Build NAPP Master Hard Disc Drive

### CD to Disk Recovery


1. Prepare NAPP CD, Recovery CD and System CD.
2. Put NAPP CD into the optical drive. Then boot up the system.
3. The system will ask you if you want to build NAPP Master HDD. Please press any key to continue.




4. NAPP CD will start to preload the system, please click [Y].



5. Select CD to Disk Recovery.



6. Put the Recovery CD to the optical drive. This step is to create image files to the system, you do not have to put the Recovery CD to the optical drive in order. Place one Recovery CD to the drive at one time till you finish all Recovery CDs.



After you place the Recovery CD to the optical drive, you will see the display below.




---



```
Please Wait for COPYING .....  
X:\images \70E40I01.HDD
```

7. Then insert the System CD to the optical drive.



```
Please Insert the System CD  
  
Please Press Any Key to Continue.  
Press any key to continue...  
—
```

8. You will see the screen displaying “PASS” when the system has built NAPP Master hard disc drive.




## Disk to Disk Recovery


1. Prepare NAPP CD, Recovery CD and System CD.
2. Put NAPP CD into the optical drive. Then boot up the system.
3. The system will ask you if you want to build NAPP Master HDD. Please press any key to continue.



4. NAPP CD will start to preload the system, please click [Y].




5. Select Disk to Disk Recovery. Then choose Single Language or Multi-Languages Recovery.  
**NOTE:** For Multi-Languages Recovery, not more than five languages could be loaded to the system.



6. Put the Recovery CD to the optical drive. This step is to create image files to the system, you do not have to put the Recovery CD to the optical drive in order. Place one Recovery CD to the drive at one time till you finish all Recovery CDs.

---



```
Please Insert Any Recovery CD


Please Press Any Key to Continue.
Press any key to continue...
-
```

After you place the Recovery CD to the optical drive, you will see the display below.



```
Please Wait for COPYING .....
X:\images \70E40I01.HDD
```

7. Then insert the System CD to the optical drive.




8. You will see the screen displaying “PASS” when the system has buit NAPP Master hard disc drive.





## Jumper and Connector Locations

### Top View




---

1	U12	CPU Socket	14	LIN1	Line-in Port
2	FAN1	Fan Connector	15	LOUT1	Line-out Port
3	SW1	SW1	16	RJ1	RJ45+RJ11
4	TPAD1	Touchpad Cable Connector	17	USB1-4	Four USB Ports
5	HDD1	HDD Connector	18	CRT1	VGA Port
6	KB1	Keyboard Connector	19	LCD1	LCD Coaxial Cable Connector
7	SPK1	Speaker Cable Connector	20	MINI1	Mini PCI Connector
8	IDE1	Optical Drive Connector	21	RTC1	RTC Battery Connector
9	U23	South Bridge	22	U15	North Bridge
10	FDD1	FDD Connector	23	PRT1	Parallel Port
11	CN1	Launch Cable Connector	24	DCIN1	DC-in Port
12	CBUS1,2	PCMCIA Slot	25	CVR1	LCD Lid Switch
13	INV1	LCD Inverter Cable Connector			



# Bottom View



- 1    U7    FIR Port
- 2    RING1    Modem Cable Connector
- 3    MDC1    Modem Card Connector
- 4    DM1    DIMM Socket 1
- 5    DM2    DIMM Socket 2

## SW1 Settings

	1	2	3	4
Password Enable	ON	X	X	X
Password Disable	OFF	X	X	X
Bootblock Enable	X	ON	X	X
Bootblock Disable	X	OFF	X	X
Adapter 90W	X	X	ON	X
Adapter 120W	X	X	OFF	X



## FRU (Field Replaceable Unit) List


---


This chapter gives you the FRU (Field Replaceable Unit) listing in global configurations of Extensa 2700. Refer to this chapter whenever ordering for parts to repair or for RMA (Return Merchandise Authorization).

Please note that WHEN ORDERING FRU PARTS, you should check the most up-to-date information available on your regional web or channel. For whatever reasons a part number change is made, it will not be noted on the printed Service Guide. For ACER AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code from those given in the FRU list of this printed Service Guide. You MUST use the local FRU list provided by your regional Acer office to order FRU parts for repair and service of customer machines.









**NOTE:** To scrap or to return the defective parts, you should follow the local government ordinance or regulations on how to dispose it properly, or follow the rules set by your regional Acer office on how to return it.






# Extensa 2700 Exploded Diagram








Picture	No.	Partname And Description	Part Number
Adapter			
		ADAPTER 120W 3PIN LITEON PA-1121-02AC REV.A	AP.T3003.002
Battery			
		RTC BATTERY	23.T30V1.001
	18	BATTERY MODULE LI-ION 8CELL 2.0 MAH SIMPLO W/ COVER	6M.T30V1.009
		BATTERY LI-ION 8CELL 2.0 MAH LI-ION SIMPLO BTP-58A1	BT.T3007.001
CASE/COVER/BRACKET ASSEMBLY			
		BATTERY COVER	42.T30V1.001
Boards			
		DC BOARD	55.T30V1.001
		WIRELESS LAN BOARD 802.11B AMBIT T60H656.02 REV.03	54.T30V1.001




Picture	No.	Partname And Description	Part Number
		LAUNCH BOARD	55.T30V1.002
		MODEM BOARD 56K AMBIT T60M283.10	54.09011.542
Cables			
		TOUCHPAD CABLE	50.T30V1.001
		COVER SWITCH CABLE	50.T30V1.002
		LAUNCH CABLE	50.T30V1.011
		MODEM CABLE	50.41T11.002
		POWER CORD US (3 pin)	27.01618.051
Case/Cover/Bracket Assembly			
	3	MINI PCI CARD PLATE W/RTC HOLDER	60.T30V1.003
	6	HINGE CAP RIGHT	42.T30V1.002

Picture	No.	Partname And Description	Part Number
	8	HINGE CAP LEFT	42.T30V1.003
	10	OPTICAL DRIVE SUPPORT BRACKET	33.T30V1.001
	15	HDD BRACKET	33.T30V1.002
	16	HDD HOLDER	33.T30V1.003
	17	LOWER CASE W/ DIMM COVER & MODEM COVER & SPEAKERS	60.T30V1.004
		MODEM COVER W/SCREW	42.T30V1.004
		DIMM COVER W/SCREW	42.T30V1.005
	19	UPPER CASE W/O COVER SWITCH CABLE & TOUCHPAD MODULE	60.T30V1.001










Picture	No.	Partname And Description	Part Number
		TOUCHPAD COVER	42.T30V1.006
		MIDDLE COVE W/LAUNCH BOARD	60.T30V1.005
Communication Module			
		WIRELESS ANTENNA RIGHT (BLACK)	50.T30V1.004
		WIRELESS ANTENNA LEFT (GRAY)	50.T30V1.005
CPU			
		INTEL CELERON PORTABILITY 2.6 GHZ 128K 400FSB for TM240	KC.NCP01.26G
		INTEL CELERON PORTABILITY 2.5 GHZ 128K 400FSB for TM240	KC.NCP01.25G
		INTEL CELERON PORTABILITY 2.4 GHZ 128K 400FSB for TM240	KC.NCP01.24G
		INTEL CELERON PORTABILITY 2.3 GHZ 128K 400FSB for TM240	KC.NCP01.23G
		INTEL CELERON PORTABILITY 2.2 GHZ 128K 400FSB for TM240	KC.NCP01.22G
		INTEL CELERON PORTABILITY 2.0GHZ 128K 400FSB for TM240	KC.NCP01.20G
		INTEL MOBILE PENTIUM 4 PORTABILITY 3.06GHZ 512K 1.53V for TM250	KC.NP001.306
		INTEL MOBILE PENTIUM 4 PORTABILITY 2.8GHZ 512K 1.53V for TM250	KC.NP001.2G8
		INTEL MOBILE PENTIUM 4 PORTABILITY 2.66GHZ 512K 1.53V for TM250	KC.NP001.266
		INTEL MOBILE PENTIUM 4 PORTABILITY 2.4GHZ 512K 1.53V for TM250	KC.NP001.2G4
FDD/Floppy Disk Drive			





Picture	No.	Partname And Description	Part Number
	13	FDD MODULE 1.44M MCI JU-226A033FC	6M.T30V1.003
		FDD MODULE 1.44M MITSUMI D353G 4515	6M.T30V1.004
		FDD DRIVE 1.44M MCI JU-226A033FC	KF.T3007.001
		FDD DRIVE 1.44M MITSUMI D353G 4515	KF.T3006.001
		FDD BRACKET	33.T30V1.005
		FDD CABLE	50.T30V1.003
HDD/ Hard Disk Drive			
		HDD 20GB 2.5" 4200RPM HGST MORAGA IC25N020ATMR04-0 08K0632	KH.02007.002
		HDD 20GB/2.5 IN./4200 RPM/IBM CASCADE IC25N020ATCS04-0 07N8325	KH.25202.001
		HDD 20GB/2.5 IN./4200RPM/ HITACHI EUCALYPTUS DK23EA	KH.32005.002
		HDD 20GB 2.5" 4200RPM TOSHIBA NEPTUNE V20 MK2023GAS	KH.02004.001
		HDD 30GB/2.5 IN./4200RPM/ HITACHI EUCALYPTUS DK23EA/ 30	KH.33005.002
		HDD 30GB 2.5" 4200RPM FUJITSU V-40 MHT2030AT	KH.03006.002
		HDD 30GB 2.5" 4200RPM HGST MORAGA IC25N030ATMR04-0	KH.03007.002
		HDD 30GB/2.5 IN./4200RPM/ TOSHIBA NEPTUNE MK3021GAS	KH.33004.001
		HDD 40GB/2.5 IN./4200RPM/ HITACHI EUCALYPTUS DK23EA-40	KH.34005.002

Picture	No.	Partname And Description	Part Number
		HDD 40GB 2.5" 4200RPM HGST MORAGA IC25N040ATMR04-0 08K0633	KH.04007.004
		HDD 40GB/2.5" IN./4200RPM/ TOSHIBA NEPTUNE MK4021GAS	KH.34004.001
		HDD 40GB 2.5" 5400RPM SEAGATE ST94011A	KH.04001.004
		HDD 40GB 2.5" 4200RPM FUJITSU V-40 MHT2040AT	KH.04006.002
		HDD 60GB/2.5 IN./4200RPM/ HITACHI EUCALYPTUS DK23EA-60	KH.06005.001
		HDD 60GB 2.5" 4200RPM HGST MORAGA IC25N060ATMR04-0 08K0634	KH.06007.002
		HDD 60GB/2.5 IN./4200RPM/ TOSHIBA NEPTUNE MK6021GAS	KH.36004.001
		HDD 60GB 2.5" 4200RPM FUJITSU V-40 MHT2060AT	KH.06006.002
		HDD 80GB 2.5" 4200RPM HGST MORAGA IC25N080ATMR04-0 08K0635	KH.08007.002
Heatsink			
	4	CPU FANSINK	34.T30V1.001
		VGA HEATSINK PLATE	34.T30V1.002
		CPU HEATSINK PLATE	34.T30V1.003
Keyboard			

Picture	No.	Partname And Description	Part Number
	2	KEYBOARD 84KEY DARFON NSK-AC61D US-INT	KB.T3007.001
		KEYBOARD 84KEY DARFON NSK-AC602 TAIWAN	KB.T3007.002
		KEYBOARD 85KEY DARFON NSK-AC60S SPANISH	KB.T3007.003
		KEYBOARD 84KEY DARFON NSK-AC603 THAI	KB.T3007.004
		KEYBOARD 85KEY DARFON NSK-AC60U UK	KB.T3007.006
		KEYBOARD 85KEY DARFON NSK-AC60G GERMAN	KB.T3007.007
		KEYBOARD 85KEY DARFON NSK-AC606 PORTUGUESE	KB.T3007.011
		KEYBOARD 84KEY DARFON NSK-AC60C CZECH	KB.T3007.015
LCD			
	7	LCD MODULE 14.1" TFT XGA CHIMEI N141X6-L01/08	6M.T30V1.005
		LCD MODULE 15" TFT XGA CHIMEI N150X3-L05	6M.T30V1.006
		LCD MODULE 15" TFT XGA HITACHI TX38D81VC1CAB	6M.T30V1.007
		LCD MODULE 15" TFT XGA AU B150XG01 V.2	6M.T30V1.008
		LCD 14.1" TFT XGA AU B141XN04 V2/5AXXX	LK.14105.005
		LCD 14.1" TFT XGA CHIMEI N141X6-L01/08	LK.1410D.001
		LCD 15" TFT XGA CHIMEI N150X3-L05	LK.1500H.001
		LCD 15" TFT XGA HITACHI TX38D81VC1CAB	LK.15004.004
		LCD 15" TFT XGA AU B150XG01 V.2	LK.15005.001
		INVERTER BOARD 14"/15" DARFON V0.21071.001	19.T30V1.001
		LCD BRACKET RIGHT FOR 14.1"	33.T30V1.006
		LCD BRACKET RIGHT FOR 15"	33.T30V1.009
	NS	LCD BRACKET LEFT FOR 14.1"	33.T30V1.007
		LCD BRACKET LEFT FOR 15"	33.T30V1.008

Picture	No.	Partname And Description	Part Number
		INVERTER CABLE	50.T30V1.007
		LCD COAXIAL CABLE	50.T30V1.008
	NS	LCD PANEL W/HINGE & LOGO	60.T30V1.008
	NS	LCD BEZEL 14.1" W/ICON LABEL	60.T30V1.006
		LCD BEZEL 15" W/ICON LABEL	60.T30V1.007
		HINGE PACK	6K.T30V1.001
Main Board			
		MAINBOARD W/LAUNCH CABLE & MODEM & MODEM CABLE & PCMCIA SLOT & RTC BATTERY	MB.T3001.001
Miscellaneous			
		LOGO	31.42S08.001
		ICON LABEL	40.T30V1.001
		TOUCHPAD SCROLL KEY	42.T30V1.007

Picture	No.	Partname And Description	Part Number
		TOUCHPAD KNOB	42.T30V1.008
		LCD SCREW RUBBER UPPER	47.T30V1.001
		LCD SCREW RUBBER LOWER	47.T30V1.002
		RUBBER FOOT	47.T30V1.003
		LCD BEZEL RUBBER UPPER	47.T30V1.004
		NAME PLATE TM250	40.T30V1.003
		NAME PLATE TM240	40.T30V1.002
Memory			
	NS	MEMORY SO-DIMM DDR266/ 128MB /INFINEON HYS64D16000GDL-7-B	KN.12802.004
		MEMORY SO-DIMM DDR266/ 128MB/0.14U /NANYA NT128D64SH4B0GM-75B	KN.12803.003
		MEMORY DDR266 128MB NANYA NT128D64SH4BBGM-75B	KN.12803.007
		MEMORY DDR266 128MB MICRON MT4VDDT1664HG- 265B2	KN.12804.004
		MEMORY DDR266 128MB MICRON MT4VDDT1664HG- 265C2	KN.12804.005
		MEMORY SO-DIMM DDR266/ 256MB/0.14U /INFINEON HYS64D32020 GDL-7-B	KN.25602.001
		MEMORY DDR266 256MB NANYA NT256D64SH8BAGM-75B	KN.25603.010
		MEMORY SO-DIMM DDR266/ 256MB/0.15U /MICRON MT8VDDT3264HDG-256B3	KN.25604.003
		MEMORY SO-DIMM DDR266 256MB MICRON MT8VDDT3264HDG-265C3	KN.25604.004
		MEMORY SO-DIMM DDR266/ 512MB/0.14U /INFINEON HYS64D64020GBDL-7-B	KN.51202.003
		MEMORY DDR333 128MB INFINEON HYS64D16000GDL-6-B	KN.12802.006
		MEMORY DDR333 256MB INFINEON HYS64D32020GDL-6-B	KN.25602.009
		MEMORY DDR333 256MB NANYA NT256D64SH8BAGM-6K	KN.25603.009

Picture	No.	Partname And Description	Part Number
		MEMORY DDR333 256MB ELPEDIA W30256AAEPI652A	KN.25609.002
		MEMORY DDR333 256MB MOCRON MT8VDDT3264HDG-335C3	KN.25604.009
		MEMORY DDR333 512MB INFINEON HYS64D64020GBDL-6-B	KN.51202.007
Optical Drive			
		CD-ROM MODULE 24X MITSUMI SR244W1	6M.T30V1.001
		DVD-ROM MODULE 8X MKE SR-8177	6M.T30V1.002
		CD-ROM DRIVE 24X W/ BEZEL MITSUMI SR244W1	KD.24X04.002
		DVD-ROM DRIVE 8X W/ BEZEL MKE SR-8177	KV.08X02.004
		OPTICAL DRIVE BRACKET	33.T30V1.004
PCMCIA slot/PC card slot			
		PCMCIA SLOT	22.T30V1.001
Pointing Device			
	NS	TOUCHPAD SYNAPTICS TM41P-357	56.17001.001
Speaker			
		SPEAKER SET	23.T30V1.002
Screws			
	NS	SCREW	86.T30V1.001
	NS	SCREW	86.T30V1.002

---

Picture	No.	Partname And Description	Part Number
	NS	SCREW	86.9A352.3R0
	NS	SCREW	86.9A353.6R0
	NS	SCREW	86.9A524.4R0
	NS	SCREW	86.9A552.2R0
	NS	SCREW	86.9A552.3R0
	NS	SCREW	86.9A552.4R0
	NS	SCREW	86.9A553.3R0
	NS	SCREW	86.9A553.4R0
	NS	SCREW	34.00015.081





## Model Definition and Configuration

---

### Model Name Definition

Model Number	LCD	CPU	Memory	HDD	CD/DVD	Battery	Wireless LAN
2703LMi	15.0" XGA	DT P4 3.2GHz/ 512K	DDR333 2x256MB	60GB	4x DVD-Dual	Li-ion	11g



## ***Test Compatible Components***

---

This computer's compatibility is a test plan released by Acer Internal Testing Department. Once the final report is available, this chapter will be revised accordingly.

## Microsoft Windows XP Environment Test

Item	Specifications
Processor	Northwood 2.60GHz/.13m/512K L2/400Mhz FSB Northwood 2.80GHz/.13m/512K L2/533Mhz FSB/HT Northwood 3.06GHz/.13m/512K L2/533Mhz FSB/HT Northwood 3.0GHz/.13m/512K L2/800Mhz FSB/HT Northwood 3.20GHz/.13m/512K L2/800Mhz FSB/HT Northwood 3.4Ghz/.13m/512K/800FSB/HT Prescott 3 GHz/1MB L2/800 FSB/HT Prescott 3.2GHz/1MB L2/800 FSB/HT Prescott 3.4GHz/1MB L2/800 FSB/HT Prescott 3.6GHz/1MB L2/800 FSB/HT Prescott 3.8GHz/1MB L2/800 FSB/HT Mobile Pentium 4 3.06GHz/512K/533 Mhz/HT Mobile Pentium 4 3.20 GHz/512K/533 Mhz/HT
Memory	128MB Infineon SO-DIMM HY64D16000GDL-6-B 256MB Infineon SO-DIMM HY64D32000GDL-6-B 256MB Nanya SO-DIMM NT256D64SH8BAGN-6KE 256MB Micron SO-DIMM MT8VDDT3264HDG-35C3 512MB Infineon SO-DIMM HYS64D64020GBDL-6-B 512MB Nanya SO-DIMM NT512D64S8HBAFM-6K
LCD	14.1" XGA TFT AU B141XN04 15" XGA TFT AUO B150XG01 LG LP150X08-A5 15" SXGA+ TFT AU B150PG01 V0
Hard Disk Drive	20G HGST Moraga IC25N020ATMR04 f/w:AD4A 20GB Toshiba Neptune MK2023GAP  30GB HGST Moraga IC25N030ATMR04 30GB Toshiba Neptune MK3021GAS 30G Fujitsu V-40 MHT2030AT 30G Seagate N1 ST93015A  40GB IBM HGST Moraga IC25N040ATMR04-0 40GB TOSHIBA Pluto 40G MK4025GAS 40G Fujitsu V40+ MHT2040AT 40G Seagate N1 ST94019A  60G HGST Moraga IC25N060ATMR04-0 60G HGST Fresno DK23FA-60 HT 60G TOSHIBA Neptune MK6021GAS  80G HGST Moraga IC25N080ATMR04 80G Pluto MK8025GAS
DVD-ROM Drive 8X	MKE SR-8177
CD-ROM Drive 24X	Mitsumi SR-224W1 QSI SCR242
DVD/CD-RW Combo	KME UJDA750 QSI SBW-242B

Item	Specifications
DVD-dual	DVD-Dual SDW-042 DVD-Dual SDW-431S DVD-Dual GWA-4040N DVD-Dual DVR K13RA
DVD-RW	DVD-RW SD-R6112
DVD-Super Multi	UJ820 DVD super multi
AC Adapter (3 pin)	Liteon Adapter 135W ADT 135W 3P 19V 0317A19135 HiPro Adapter 135W
Power Cord	King Cord
Battery Li-Ion, 8 cells	SANYO BTP-60A1 SIMPLO BTY PK Panasonic
Network Adapters	
LAN Ethernet/10baseT/100baseT	3Com Etherlink III 3C589D IBM EtherJet CardBus Adapter 10/100 Intel Ether Express Pro/100 Mobile Adapter MBLA3200 Xircom CardBus Ethernet 10/100 32 Bit CBE-10/100BTX
Multifunction Card (Combo)	3Com Megahertz 10/100 LAN + 56K Modem PC Card Xircom RealPort CardBus Ethernet 10/100 + Modem 56
LAN Token Ring	IBM Token Ring 16/4 Adapter II
Wireless LAN Card	IBM Wireless LAN Cardbus Adapter Intel Pro-Wireless LAN PC Card Proxim Skyline 802.11a Cardbus PC Card Cisco Aironet 350 series Wireless Lan Card NeWeb Wireless Lan Card 802.11b
Modem Adapters	
Modem (up to 56K)	3Com Megahertz 56K Modem PC Card Xircom Credit Card Modem 56 IBM 56K Double Jack Modem
ISDN	US Robotics Megahertz 128K ISDN Card 405R17T7117M IBM OBI International ISDN PC Card
I/O Peripheral	
I/O - Display	Acer 211c 21" Viewsonic PF790 19" Acer FP751 17" TFT LCD IBM Color TFT LCD 14" Compaq Color Monitor NET Color Monitor 20" Mozo 17" TFT LCD (DVI)
I/O - Projector	NEC MultiSync MT-1040
I/O - Legacy (Parallel) Printer/Scanner	Canon BJC-600J Epson Stylus Color 740 Parallel Interface HP DeskJet 890C HP DeskJet 880C Parallel Interface HP LaserJet 6MP HP LaserJet 2200
I/O - IR Printer	HP LaserJet 6MP use IR HP LaserJet 2200 use IR

Item	Specifications
I/O - USB Keyboard/Mouse	Chicony USB Keyboard KU-8933 Microsoft Natural Keyboard Pro Acer Aspire USB mouse Logicoool US Mouse Logitech Cordless Mouseman Wheel USB Interface Logitech USB Wheel Mouse M-BB48 Microsoft IntelliMouse Optical USB Interface
I/O - Legacy (PS2/Serial) Keyboard/Mouse	IBM 101 key keyboard IBM 109 key keyboard Acer PS2 keyboard Acer KB-101A IBM Numeric Keypad III IBM Numeric Keypad Acer Mouse IBM PS2 Mini Mouse IBM PS2 Mouse Logitech Cordless MouseMan Wheel PS2 interface Logitech Serial Mouse M-M35 Microsoft IntelliMouse PS2 interface Microsoft IntelliMouse Optical PS2 interface Logitech First Mouse Three Button Serial Mouse
I/O - USB (Printer/Scanner)	Epson Stylus Color 740 USB interface HP DeskJet 880C USB interface Canon CanonScan D1250 (USB 2.0, JP OS only) HP ScanJet 3300C Color Scanner
I/O - USB (Speaker/Joystick))	JS USB Digital Speaker Panasonic USB Speaker EAB-MPC57USB AIWA Multimedia Digital Speaker Microsoft SideWinder Precision Pro Joystick Logitech WingMan RumblePad
I/O - USB Camera	Intel Easy PC Camera Logitech QuickCam Express Internet Logitech QuickCam Home PC Video Camera Orange Micro USB 2.0 Web Cam
I/O - USB Storage Drive	Logitech CDRW +DVDROM combo USB interface Iomega USB Zip 250MB
I/O-USB Flash Drive	IBM 32MB USB Memory key Apacer USB Handy Drive 32MB Apacer USB Handy Drive 256MB
I/O - USB Hub	Belkin 4 Port USB Hub Eizo I Station USB Hub Elecom USB Hub 4 Port Sanwa USB Hub 4 Port 4 Port Hub USB 2.0
I/O - Access Point (802.11b)	Hitachi DC-CN3300 Lucent RG-1000 Lucent WavePoint-II Cisco Aironet 350 Orinoco AP-500
I/O Access Point (802.11a/b)	Intel Dual Pro/Wireless 5000
I/O Access Point (802.11a)	Intel Pro/Wireless 5000

Item	Specifications
PCMCIA	
PCMCIA - ATA	IBM Microdrive 340MB IBM Microdrive 1G Iomega Click! 40MB Sony Memory Stick 64MB Sandisk Flash Card 20MB Apacer SD Flash Card 128MB Apacer SD Flash Card 256MB Transcend SD Card 32MB Transcend SD Card 256MB Hagiwara sys-com SD Card 256MBT
PCMCIA - USB 2.0	Apricorn EZ-USB2.0 Cardbus PC Card DTK USB 2.0 2Port CardBus Host Controller Adaptec USB2CONNECT
PCMCIA - 1394	Buffalo 1394 Interface Cardbus IFC-ILCB/DV I-O Data 1394 Interface Cardbus CB1394/DVC Pixela 1394 Cardbus PC Card PIX-PCMC/FW1
PCMCIA-SCSI	Adaptec 1408 or B SCSI CB NewMedia Bus Toaster SCSI II
PCMCIA - Bluetooth	IBM Community Bluetooth PC Card Toshiba Bluetooth PC Card





## Online Support Information

---

This section describes online technical support services available to help you repair your Acer Systems.

If you are a distributor, dealer, ASP or TPM, please refer your technical queries to your local Acer branch office. Acer Branch Offices and Regional Business Units may access our website. However some information sources will require a user i.d. and password. These can be obtained directly from Acer CSD Taiwan.

Acer's Website offers you convenient and valuable support resources whenever you need them.

In the Technical Information section you can download information on all of Acer's Notebook, Desktop and Server models including:

- ☐ Service guides
- ☐ User's manuals
- ☐ Training materials
- ☐ Main manuals
- ☐ Bios updates
- ☐ Software utilities
- ☐ Spare parts lists
- ☐ Chips
- ☐ TABs (Technical Announcement Bulletin)

For these purposes, we have included an Acrobat File to facilitate the problem-free downloading of our technical material.

Also contained on this website are:

- ☐ Detailed information on Acer's International Traveller's Warranty (ITW)
- ☐ Returned material authorization procedures
- ☐ An overview of all the support services we offer, accompanied by a list of telephone, fax and email contacts for all your technical queries.

We are always looking for ways to optimize and improve our services, so if you have any suggestions or comments, please do not hesitate to communicate these to us.

**A**

AC Adapter 28  
AFLASH Utility 44  
Audio 19

**B**

Battery 28  
BIOS 19  
    package 19  
    ROM size 19  
    ROM type 19  
    vendor 19  
    Version 19  
BIOS Supports protocol 19  
BIOS Utility 32  
    Basic System Settings 37  
    Navigating 33  
    Onboard Device Configuration 40  
    Startup Configuration 39  
    System Information 33  
    System Security 44  
Board Layout  
    Bottom View 5  
    Top View 4  
brightness  
    hotkeys 16

**C**

CardBus 27  
CD-ROM Interface 22  
Chipsets 19  
contrast  
    hotkeys 16  
Controllers 19  
Core logic 19  
CPU  
    core voltage 19  
    I/O voltage 19  
    package 19  
    type 19

**D**

Disassembly Flowchart 48  
display  
    hotkeys 16  
Display Standby Mode 30  
DVD-ROM Interface 22

**E**

Environmental Requirements 30  
Error Symptom-to-Spare Part Index 77  
External CD-ROM Drive Check 73

**F**

Flash Utility 44  
FRU (Field Replaceable Unit) List 98

**H**

Hard disk 19, 21  
Hard Disk Drive Module  
    Disassembly 53  
Hard Disk Standby Mode 30  
Hardware Specifications and Configurations 19  
HDD 19, 21  
Hibernation Mode 30  
Hibernation mode  
    hotkey 16  
Hot Keys 16

**I**

Intermittent Problems 84

**J**

Jumper and Connector Locations  
    Bottom View 96  
    Top View 95

**K**

Keyboard 19, 28  
Keyboard or Auxiliary Input Device Check 73

**L**

L2 cache 19  
LCD 28

**M**

Mechanical Specification 30  
Memory Check 74  
Modem 21

**N**

Notebook Manager  
    hotkey 16

## O

Online Support Information 120

## P

Panel 5, 96

Bottom 10

Parallel Port 27

PC Card 27

PCMCIA 27

Power Management 29

Power System Check 74

Battery Pack 76

Power Adapter 75

## R

RTC 19

## S

Second Level Cache 19

speakers

hotkey 16

Standby Mode 29

Super I/O 19

System Check Procedures 73

System Diagnostic Diskette 45

System Memory 20

System Utilities 32

System Utility Diskette 45

## T

Temperature 30

Test Compatible Components 114

Touchpad 19

touchpad

hotkey 16

Touchpad Check 76

Troubleshooting 72

## U

Undetermined Problems 85

USB 27

utility

BIOS 32

## V

Video 26

Resolutions 26, 27