

# EPSON

## TM-L90P(011)

Page 1

REF	PART NO	DESCRIPTION	SPEC	QTY
101	1033669	SCREW,DETECTOR ADJUSTMENT		1
102	1062174	LOGO PLATE,AB		1
103	1039482	SEAL,CAUTION,HEAD B		1
104	1046466	SPRING,BLADE HOLDER		1
105	1051988	SCREW,SWITCH,I		2
106	1061077	SEAL,CAUTION,C		1
107	1057233	FRAME,R		1
108	1057235	FRAME,FRONT		1
109	1057236	PLATE,FRAME STRENGTHEN,R		1
110	1057237	PLATE,FRAME STRENGTHEN,L		1
111	1057238	FRAME CIRCUIT BOARD,A		1
112	1061959	HOLDER,BM DETECTOR		1
113	1057241	PLATE,SPRING HOLDER		1
114	1057246	FIXED BLADE		1
115	1060285	GEAR,REDUCTION,C		1
116	1060286	GEAR,REDUCTION,D		1
117	1057253	DAMPER,PAPER FEED MOTOR		3
118	1057254	GROUND PLATE,MOTOR		1
119	1057255	FRAME,CENTER		1
120	1061960	HOLDER,LABEL		1
121	1063778	HOLDER,LED ASS'Y		1
122	1061962	ROLLER,PAPER HOLD		8
123	1057259	SPRING,TENSION PLATE		2
124	1057260	PLATE SPRING,COVER		1
125	1057264	SPRING,HEAD HOLDER		2
126	1061964	GUIDE,LABEL		1
127	1057271	COVER,ARM,AA		1
128	1057278	LEVER,COVER OPEN		1
129	1057279	SHAFT,LEVER		1
130	1057281	BUTTON,LEVER,AA		1
131	1057282	BUTTON,FEED,AA		1
132	1057283	SPACER,FEED		1
133	1057284	SHAFT,COVER TURNING		2
134	1057285	HOLDER,SWITCH PANEL		1
135	1057286	SHEET,FEED,A		1
136	1061887	CASE,MAIN ASS'Y,AA		1
139	1057290	COVER,CUTTER,AA		1
140	1057291	RUBBER FOOT,A		4
141	1057292	COVER,CONNECTOR,AA		1
142	1057318	FRAME,L ASS'Y,A		1
144	1061970	LEVER,N.E.DETECTOR		1
145	1061969	HOLDER,N.E.DETECTOR		1
146	2014923	MICRO-SWITCH		1
147	1061956	THERMAL PRINT HEAD ASS'Y,C		1
148	1051986	SCREW,MANUAL CUTTER		3
149	1057325	FRAME,CUTTER ASS'Y		1
150	1059942	COVER,PAPER CUTTER ASS'Y,B		1
151	1057330	MOTOR,CUTTER SUB ASS'Y		1
152	1062746	COVER,ROLL PAPER ASS'Y,BA		1
153	1057529	SPACER,3X4X4,F/ZN		3
154	1058459	COVER,DIP SWITCH		1
155	1061974	LABEL,OPERATION,BA		1
156	1061958	HOLDER,LABEL PLATEN		1
157	1057295	COVER,POWER SWITCH,AA		1

# EPSON

## TM-L90P(011)

Page 2


158	1062635	LABEL,SWITCH PANEL,BA		1
159	1061976	RUBBER FOOT,C		4
160	1058460	TAPE,COVER		1
162	1057324	AUTO CUTTER UNIT		1
163	1061889	PLATEN ASS'Y		1
164	1052054	SHAFT HOLDER,PAPER FEED ROLLER		1
165	1060852	PLATE,LOWER		1
166	1062276	COVER,DETECTOR ASS'Y		1
167	1057245	MANUAL CUTTER		1
169	1061963	PLATE,HOLDER AUXILIARY		1
170	1061965	SHAFT,SPACER GUIDE		1
171	1061967	PLATE,SPACER GUIDE		1
172	1061973	SPACER,HINGE		2
173	1061966	SPACER,LABEL		1
174	1061971	GUIDE,PAPER OUTLET,AA		1
175	1061972	TAPE,PAPER OUTLET		1
176	1063777	SHEET,HOLDER GUIDE		1
177	1066751	SPACER,A		1
178	1066752	SPACER,B		1
179	1005881	MINI CLAMP		1
180	1067944	PLATE,SHIELD		1
E1	B150300311	RETAINING RING	TYPE-E(1.5),F/ZN	1
E2	B150300611	RETAINING RING	TYPE-E(3)	10
N1	B070100311	HEXAGON NUT	M3	4
S01	1012350	C.B.P-TITE,3X10,F/ZN		7
S02	1035668	C.C.P-TITE SCREW,3X8,F/ZN		4
S03	B310206411	C.B.B.SCREW,4X12,F/ZN		1
S04	B300204211	C.B.S. SCREW	M3X6	9
S05	B300204311	C.B.S. SCREW	M3X8	2
S06	B302404211	C.P.S.(O) SCREW	M3X6	12
S07	1017753	C.B.B-TITE SCREW	2X8	5
S09	1006769	C.B. SCREW	2X2.5,F/ZN	2
S10	B300304211	C.C.S. SCREW	M3X6	1
W1	B100156912	PLAIN WASHER	M3X0.3X8	2
201	2047337	MAIN CIRCUIT BOARD UNIT,BA	,	1
202	2048039	PARALLEL I/F CIRCUIT BOARD UNIT,D	,	1
205	2047184	MOTOR,PAPER FEED,B	,	1
206	2036015	LEAD WIRE,N.E.DETECTOR	...	1
207	2036016	FFC,HEAD		1
208	2036054	FFC,SWITCH CIRCUIT BOARD		1
209	2036092	SUB CIRCUIT BOARD ASS'Y,AA	TM-T800	1
210	2036093	SWITCH CIRCUIT BOARD ASS'Y,AA	TM-T800	1
211	2048569	FERRITE CORE		1
213	2049055	CIRCUIT BOARD,BM PAPER DETECTOR ASS'Y,B		1
51	B703600001	GREASE G-36 (40GR)	M-1541/M-820	1
52	1033657	GREASE G-45	CR-510	1

END

# EPSON

## TM-L90P(011)

Page 3




TM-L90 NO.1

REV.01

# EPSON

## TM-L90P(011)

Page 4



TM-L90 NO.2

REV.01