

## GENERAL SERVICE PARTS FOR MODEL HS-20/21 SERIES

1. The Ref. no's corresponds to the same numbers in the exploded diagram on the subsequent pages.
2. The availability for ISP (Initially-Supplied Parts) differs depending on the destination. For details, refer to the ISP List supplied specifically by Kyocera.
3. Those parts bearing numbers in the diagram but not listed in the catalogue are not suppliable as a general supply part.
4. Dates are indicated as *yy.mm.dd*.

REF.NO	PART CODE	PART CODE 1	DESCRIPTION	ISP	USED	HS-20					HS-21				
						Germany	U.K.	France	Australia	U.S.	Germany	U.K.	France	Australia	U.S.
	5AAPRSSR2001AH		P.W.BOARD ASSY	1	1	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
	5AAPRIFR2001BH		P.W.BOARD ASSY		1	No	No	No	No	No	No	No	No	No	No
	5AAPRDVR2001CH		P.W.BOARD ASSY	1	1	No	No	No	No	No	No	No	No	No	No
01-001	5MVB877SH010		COVER		1						Yes	Yes	Yes	Yes	Yes
01-002	5MVB872SH012		LID TOP		1						Yes	Yes	Yes	Yes	Yes
01-004	5MVX211DB011		LEVER LOCK		2						Yes	Yes	Yes	Yes	Yes
01-005	5MVB872SH015		LID REAR		1						Yes	Yes	Yes	Yes	Yes
01-006	5MMX222LD010		SPRING ROLLER B	1	2	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
01-007	5MVS739SH001		COVER CONNECTOR		1						Yes	Yes	Yes	Yes	Yes
01-008	5MMX711AD002		BRUSH EXIT	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
01-009	5MVM273DB003		ROLLER PINCH	1	8	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
01-010	5MMX621LX001		SPRING ROLLER A	1	3	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
01-011	5MML321LD003		SPRING TOP		3						Yes	Yes	Yes	Yes	Yes
01-012	5MMX211LD009		SPRING FU		2						Yes	Yes	Yes	Yes	Yes
02-001	5MVX877SH001		BASE		1						Yes	Yes	Yes	Yes	Yes
02-002	5MVX866SH007		GUIDE INNER		1						Yes	Yes	Yes	Yes	Yes
02-003	5MVS667SH002		LID PWB		1						Yes	Yes	Yes	Yes	Yes
02-004	5MVX642SH004		LEVER SENSOR		1						Yes	Yes	Yes	Yes	Yes
02-005	5MVX542DB002		HOLDER SWITCH		1						Yes	Yes	Yes	Yes	Yes
02-006	5MVX832SB006		GUIDE FLAP		1						Yes	Yes	Yes	Yes	Yes
02-007	5MVG368DB001		GEAR Z28-P56		1						Yes	Yes	Yes	Yes	Yes
02-008	5MVG148DB018		GEAR Z14-Z36		1						Yes	Yes	Yes	Yes	Yes
02-009	5MVG127DB029		GEAR Z14		1						Yes	Yes	Yes	Yes	Yes
02-010	5MVG127DB030		GEAR FEED Z14		1						Yes	Yes	Yes	Yes	Yes
02-011	5MVG327DB003		PULLEY P17		3						Yes	Yes	Yes	Yes	Yes
02-012	5MVM177DB004		BELT IDLE PULLEY		1						Yes	Yes	Yes	Yes	Yes
02-013	5MMS777SL005		FRAME RIGHT		1						Yes	Yes	Yes	Yes	Yes
02-014	5MMX822SL003		BRACKET HOOK		1						Yes	Yes	Yes	Yes	Yes

REF.NO	PART CODE	PART CODE 1	DESCRIPTION	ISP	USED	HS-20					HS-21				
						Germany	U.K.	France	Australia	U.S.	Germany	U.K.	France	Australia	U.S.
02-015	5MMS767SL006		FRAME LEFT		1						Yes	Yes	Yes	Yes	Yes
02-016	5MVM196DB003		PLATE ENCODER		1						Yes	Yes	Yes	Yes	Yes
02-017	5MML623BD001		PLATE EARTH		1						Yes	Yes	Yes	Yes	Yes
02-018	5MMT875SN001	5MMT875SN007	ROLLER EXIT	1	1	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No
02-018	5MMT875SN007		ROLLER EXIT	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-019	5MMT875SN002	5MMT875SN008	ROLLER FEED A	1	1	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No
02-019	5MMT875SN008		ROLLER FEED A	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-020	5MMT875SN003	5MMT875SN009	ROLLER FEED B	1	1	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No
02-020	5MMT875SN009		ROLLER FEED B	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-021	5MMW161LD014		SPRING SENSOR	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-022	5MVM150RB007		BELT MOTOR Z70	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-023	5MVM180RB014		BELT TRANS Z177	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-024	5AACCNLX0GEA		CONN. CORD S00672		1						Yes	Yes	Yes	Yes	Yes
02-025	5MMM176CJ005		BUSHING SBK	1	6	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-026	5AAYHS1***04		DC MOTOR ASSY	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-027	5AAYHS1***05		SOLENOID ASSY	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-028	5ESM010235***01		MICRO SWITCH	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-029	5MMK224FJ001		MAGNET		2						Yes	Yes	Yes	Yes	Yes
02-030	5MMS227SL003		PLATE MAGNET		4						Yes	Yes	Yes	Yes	Yes
02-031	5AACCNLY0GEA		CONN. CORD S00577		1						Yes	Yes	Yes	Yes	Yes
02-033	5AACCNLX1GEA		CONN. CORD S00673		1						Yes	Yes	Yes	Yes	Yes
02-034	5AACCNLX2GEA		CONN. CORD S00674		1						Yes	Yes	Yes	Yes	Yes
02-035	5MVS808RB008		RUBBER MOTOR		1						Yes	Yes	Yes	Yes	Yes
02-036	5MVS606RB008		RUBBER SCREW		2						Yes	Yes	Yes	Yes	Yes
02-036	5AAYHS1***06		PWB UNIT AAPRDVR2001	1	1	Yes	Yes	Yes	Yes	Yes	No	No	No	No	No
02-036	5AAYHS21**02		PWB UNIT	1	1	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
02-037	5AAPRSSR2001AH		P.W.BOARD ASSY	1	1	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
02-037	5MVS116RB009		RUBBER STOPPER		1						Yes	Yes	Yes	Yes	Yes
02-038	5MMT163SZ019		SCREW MOTOR		2						Yes	Yes	Yes	Yes	Yes
02-039	5EYBZ2051000101		FERRITE CORE		1						Yes	Yes	Yes	Yes	Yes
02-040	5MVS222KF007		TAPE EARTH		2						Yes	Yes	Yes	Yes	Yes
02-041	5MMX321SM001		CORD KEEP		1						Yes	Yes	Yes	Yes	Yes
02-26A	5EZND2405301*01		DC MOTOR		1						Yes	Yes	Yes	Yes	Yes
02-26B	5AACCNLX3GEA		CONN. CORD S00576		1						Yes	Yes	Yes	Yes	Yes
02-26C	5MMG327AA001		PULLEY PINION P14		1						Yes	Yes	Yes	Yes	Yes

REF.NO	PART CODE	PART CODE 1	DESCRIPTION	ISP	USED	HS-20					HS-21				
						Germany	U.K.	France	Australia	U.S.	Germany	U.K.	France	Australia	U.S.
02-27A	5EZSA2401020305		SOLENOID TDS-KN07A		1						Yes	Yes	Yes	Yes	Yes
02-27B	5MMW266LD004		SPRING SOLENOID		1						Yes	Yes	Yes	Yes	Yes
02-27C	5MVS317DH001		PLATE JOINT SOL		1						Yes	Yes	Yes	Yes	Yes
02-27D	5MBP2514WXSP		SPRING PIN		1						Yes	Yes	Yes	Yes	Yes
401	5AAKHS21**01		PACKING ASSY		1	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
401	5AAKHS20S*01		PACKING ASSY		1	No	No	No	No	No	No	No	No	No	No
401A	5KKSHS21**01		OUTER CARTON		1	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes
401A	5KKSHS20S*01		OUTER CARTON OEM		1	No	No	No	No	No	No	No	No	No	No

