



OPTIONS IMPRIMANTES

PF-3 / PF-4

NOMENCLATURE

04-12-1998

PF-3 / PF-4 Pièces détachées

Table des matières

Unité de chargement papier (Fig.1).....3

Introduction

Les figures qui suivent représentent l'assemblage de l'imprimante ou des options, par sous-ensembles.

Les informations suivantes sont indiquées après chaque pièce :

N°	N° de la pièce dans l'éclaté
Référence.....	Référence de la pièce
Description	Description de la pièce (en anglais)

Seules les pièces en caractères GRAS peuvent être commandées.

Toutes les autres pièces sont mentionnées à titre indicatif et ne sont pas disponibles.




Fig.1 – Unité de chargement papier

N°	Référence	Description
08-001	AVFEEDR012	BASE FEEDER ASSY
08-003	VS836SH001	COVER REAR
08-004	VX764DDC01	COVER EMPTY
08-006	AVCASET164	PAPER CASSETTE M
08-006	AVCASET165	PAPER CASSETTE LETTER/LEGAL
08-008	V0211RB019	RUBBER CORD
08-009	AVCOVER167	COVER GUIDE ASSY
08-011	AYF620**30	LEVER EMPTY ASSY
08-012	AYF820**32	PLATE GEAR B ASSY
08-013	AYF820**31	LOWER FEED ASSY
08-014	AYF820**34	COVER FEEDER ASSY
08-018	ACCNHK9GEA	CONN. CORD ASSY
08-022	APRZZC1024AH	PWB ASSY KP-189
08-024	APRSWC1002AH	PWB ASSY KP-140
08-026	APRZZC1025AH	PWB ABSY KP-196
08-027	ML163LD001	ROU ER EARTH F
08-028	MU383SD001	STAY RIGHT
08-029	AVBRCKT051	STAY LEFT ASSY
08-031	MU771U3C01	CASSETTE EARTH B
08-032	MZ663U001	FEEDER EARTH R
08-034	BSPB2604NZ	BIND HEAD SCREW