


## Table of Contents:



### **Lexmark 4037-05E Laser Printer**


asm_1	Covers
asm_2	Left Side Frame
asm_3	Frame and Redrive [1 of 2]
asm_3A	Frame and Redrive [2 of 2]
asm_4	Top Cover
asm_5	Standard Paper Tray
asm_6	Fuser
asm_7	Electronics
asm_8	Options [No Illustration]
asm_9	Optional Paper Tray [14 INCH - 150 Sheet]
asm_10	250 Paper Option Without Tray
asm_11	Optional Paper Tray [11/14 INCH - 250 Sheet]
asm_12	Publications [No Illustration]

This document was compiled using the information from the Lexmark Parts Catalog CD. This document is being offered as a reference guide for parts information and description purposes only, and is not being offered for sale or for any other purposes than those stated above.




Name	PartNumber	Description
NS	1364401	Operator Panel Ground Cable
01	1363472	Right Cover
03	1381311	Parts Packet, Screws, Lockwashers
04	1039170	Machine Pad
05	1363554	Logo [4037-05E]
06	1363475	Left Side Cover
07	1381309	Parts Packet, [Clips, Rings, Washers, Standoff]
08	1363551	Front Door Asm
10	1381295	Front Cover Asm
11	1363437	Operator Panel Bezel
12	1363503	Operator Panel Button Card
13	1381286	Operator Panel Card
14	1381310	Parts Packet, Springs
15	1381311	Parts Packet, Screws, Lockwashers
16		
18	1363202	Operator Panel Cable
19	1381311	Parts Packet, [Screws, Lockwashers]
20	1363185	Outer Deflector
21	1363186	Lower Deflector
22	1381310	Parts Packet, Springs
23	1363531	Rear Exit Door
24	1363532	Rear Exit Support
25	1363558	Rear Exit Dorr Extension

## 4037\_05E asm\_2 - Left Side Frame




Name	PartNumber	Description
01	1381287	Left Side Bracket
02	1363617	Gear 12
03	1381306	Motor Torquer
04	1363621	Coupling Actuator
05	1381310	Parts Packet, Springs
06		
07	1381307	Paperfeed Motor Asm
08	1363209	Motor Cable
09	1381310	Parts Packet, Springs
10	1363647	Cam Follower
11	1363648	Coupler Asm
12	1381309	Parts Packet, [Clips, Rings, Washers, Standoff]
13	1363658	Tar Coupling Shaft
14	1381309	Parts Packet, [Clips, Rings, Washers, Standoff]
15	1381298	Input / Exit Sensor
16	1363757	Input Sensor Flag
17	1363749	D-Roll Asm
18	1363674	Release Bellcrank
19	1381310	Parts Packet, [Springs]
20	1363687	Prealigner Bellcrank Asm
21	1363688	Metering Bellcrank Asm
22	1381310	Parts Packet, [Springs]
23		
24	1381308	Tray Present Switch Block
25	1363203	Input Sensor Cable
26	1363766	Skew Roller Bracket
27	1363767	Skew Roller
28	1381311	Parts Packet, [Screws, Lockwashers]



Name	PartNumber	Description
NS	1363772	Fan Mounting Asm
01	1381318	Frame Asm
02	1039170	Machine Pad
03	1381311	Parts Packet, [Screws, Lockwashers]
04	1381300	Fan [With Cable]
05	1363771	Fan And AC Switch Bracket
06	1381320	Vertical Contact Block Asm
07	1381311	Parts Packet, [Screws, Lockwashers]
08	1381316	Horizontal Contact Block Asm
09	1381311	Parts Packet, [Screws, Lockwashers]
10	1363981	Guide Paper




# 4037\_05E asm\_4 - Top Cover




Name	PartNumber	Description	Name	PartNumber	Description
	1381290	LED Circuit Card	21	1381288	Charge Roll CBM
NS	1363201	Power Cable	22	1363549	LH Roll Bellcrank
	1363200	Signal Cable	23	1381289	Prinhthead Asm
01	1363431	Top Cover Latch	25	1363710	Actuator Block
02	1363432	Top Cover Button	26	1363135	Belt
03	1039333	Feed Roller	27	1363173	Upper Shaft Asm
04	1363433	Button Latch Bellcrank	28	1363176	Lower Shaft Asm
05	1381310	Parts Packet, [Screws]	29	1381311	Parts Packet, [Screws, Lockwashers]
06			32	1381310	Parts Packet, [Springs]
07	1381311	Parts Packet, [Screws, Lockwashers]	34	1381311	Parts Packet, [Screws, Lockwashers]
07A	1381310	Parts Packet, [Springs]	36	1381309	Parts Packet, [Clips, Rings, Washers, Standoff]
08	1412159	Top Cover [4037]	37	1363576	Upstop Link Asm
09	1363536	Top Cover Pivot Shaft	38	1363721	Left Charge Roll Mounting Bushing
10	1363534	Top Inner Cover	39	1363724	Right Charge Roll Mounting Bushing
11			40	1363723	Charge Roll Cable
12	1412159	Top Cover [4037]	42	1363743	Charge Roll Contact Housing
13			43	1363514	Charge Roll Contact Pin
14	1363527	LH Top Cover Bellcrank	44		
15	1363544	RH Top Cover Bellcrank	45	1381310	Parts Packet, [Springs]
16	1363596	RH Top Cover Hinge	46		
17	1363597	LH Top Cover Hinge			
18	1381310	Parts Packet, [Springs]			
19	1363538	RH Roll Bellcrank			
20	1381310	Parts Packet, [Springs]			

## 4037\_05E asm\_5 - Standard Paper Tray




Name	PartNumber	Description
01	1364928	Standard Paper Tray
02	1363468	Tray Liner [11INCH]
03	1363457	Side Restraint
04	1363448	Back Restraint
05	1363456	Corner Buckler
06	1363464	Plate Asm
07	1381310	Parts Packet, [Springs]
08	1363837	Paper Stack Flag
09	1381310	Parts Packet, [Springs]
10	1363469	Lift Bracket
11	1363813	Lever Asm
12	1381311	Parts Packet, [Screws, Lockwashers]
13	1381309	Parts Packet, [Clips, Rings, Washers, Standoff]
14	1363588	Lift Shaft
15	1363452	Right Stack Height Label
16	1363581	Left Stack Height Label
17	1363587	Lift Spring
19	1381310	Parts Packet, [Springs]



Name	PartNumber	Description
NS	1363599	Fuser Ground Strap
01	1381621	[X] Fuser Asm. 110V [4037]
	1381619	Fuser Asm [220V]
02	1381311	Parts Packet, [Screws, Lockwashers]
03	1363168	Rebend Shaft Asm
04	1363188	Fuser Cover
07	1381311	Parts Packet, [Screws, Lockwashers]
08	1381524	Lamp 220V
08A	1381294	Hot Roll Asm
08	1381523	Lamp 110V
09	1381297	Thermistor Asm
10	1381311	Parts Packet, [Screws, Lockwashers]
13	1363207	Fuser Power Cable
15A	1363145	Thermal Fuse Clip
15	1381546	Thermal Fuse B/M
19	1039251	Gear
22	1363142	Left Contact Asm
23	1328437	Right Contact Asm
24	1381311	Parts Packet, [Screws, Lockwashers]
25	1381322	Detack Housing Asm
26	1363205	Thermistor And Exit Sensor Cable






Name	PartNumber	Description
01	1381508	[X] System Board W/O EPROM [4037-05E]
02	1381311	Parts Packet, [Screws, Lockwashers]
02A		
03	1381309	Parts Packet, [Clips, Rings, Washers, Standoff]
04	1381301	[X] Power Supply [110V]
05	1381332	Power Supply [220V]
06	1381311	Parts Packet, [Screws, Lockwashers]
07		
	1342514	Line Cord US 8FT.
	1342530	Line Cord Power HV
	1342532	Line Cord, S. Africa
	1342533	Line Cord, Switzerland
08	1342534	Line Cord Power HV
	1342535	Line Cord, Denmark
	1342536	Line Cord Power, 6FT. HV
	1342537	Line Cord, Israel
	1342543	Line Cord, UK




Name	PartNumber	Description
	1364936	1MB-Memory
	1363571	Memory 2MB
	1364907	Memory 4MB
	1381317	Font SIMM 23T1 [1MB]
NS	1364916	Flash SIMM 256K
	1364917	Flash SIMM 1MB
	1364918	Flash SIMM 2MB [AFE ONLY]
	1363110	Serial Interface Card [OPTION]
	1364881	Cable, Serial [50 FT.]

4037\_05E asm\_9 - Optional Paper Tray [14 INCH - 150 Sheet]




Name	PartNumber	Description
01	1364929	Paper Tray [14 INCH - 150 Sheet]
02	1363571	Tray Liner [14 INCH]
03	1363457	Side Restraint
04	1363448	Back Restraint
05	1363456	Corner Buckler
06	1363464	Plate Asm
07	1381310	Parts Packet, [Springs]
08	1363837	Paper Stack Flag
09	1381310	Parts Packet, [Springs]
10	1363469	Lift Bracket
11	1363813	Lever Asm
12	1381311	Parts Packet, [Screws, Lockwashers]
13	1381309	Parts Packet, [Clips, Rings, Washers, Standoff]
14	1363588	Lift Shaft
15	1363573	Paper Tray Cover [14INCH]
18	1363587	Lift Spring
19	1363452	Right Stack Height Label
20	1363581	Left Stack Height Label

4037\_05E asm\_10 - 250 Paper Option Without Tray



Name	PartNumber	Description
01	1039260	Prealigner Gear
02	1039540	D-Roller Tire
03	1363797	D-Roll Asm
04	1039542	Lever Asm
05	1039545	Engage Gear
06	1039546	Transfer Gear
07	1039554	Paper Weight
08	1363208	Tray Sense Cable
09	1381306	Motor Torquer
10	1363790	Base Asm [250 Option]
11	1039170	Machine Pad
12	1363791	Base Deflector [250 Option]
13	1381319	Gear Block Asm
14	1363794	Prealigner Roller Asm
15	1363796	Gear 24T
16	1363799	Gear, 42/78T
17	1381305	Tray Sense Board
18	1363830	Switch Lever
19	1381310	Parts Packet, [Springs]
20		
21	1381311	Parts Packet, [Screws, Lockwashers]
22		

4037\_05E asm\_11 - Optional Paper Tray [11/14 INCH - 250 Sheet]



Name	PartNumber	Description
01	1364930	Tray Asm [11 INCH - 250 Sheet]
	1364931	Tray Asm [14 INCH - 250 Sheet]
02	1363840	Bellcrank Roller Asm
03	1363448	Back Restraint
04	1363837	Paper Stack Flag
05	1381310	Parts Packet [Springs]
06	1363456	Corner Buckler
07	1381310	Parts Packet, [Springs]
08	1363464	Plate Asm
09	1363468	Tray Liner [11 INCH]
	1363571	Tray Liner [14 INCH]
10	1363806	Lift Bellcrank
11	1381310	Parts Packet, [Springs]
12	1363810	Lift Arm Shaft
13	1363820	Paper Side Restraint
14	1363822	Left Stack Height Label
15	1363824	Right Stack Height Label
16	1381311	Parts Packet, [Screws, Lockwashers]
17	1363573	Paper Tray Cover [14 INCH]
18	1363813	Lever Asm
19	1381309	Parts Packet [Clips, Rings, Washers, Standoff]



Name	PartNumber	Description
	1363341	Users REF 4037
	1425161	What's New Booklet [4037]
	1363350	Help Book 4037
	1373373	Control Card
NS	1363363	Tech Ref 4037
	1363359	Service Manual 4037
	1363321	Service Training Kit [403705E]
	43H1753	OBSOLETE USE - 12G1752

[top](#)